

INSTRUCTIONS

300-9000-2

HARDWARE FOR 300-9000 LASER LEVEL

- 1) Thread 1/4" x 20 x 3/4" set screw into bottom of laser. Snug up set screw with wrench taking care not to over tighten.
- 2) Place one washer over set screw and insert set screw through base plate. Install second washer on bottom of base plate and thread on self-locking nut. Carefully tighten nut until laser can be rotated easily by hand, but does not have excessive play.
- 3) Coat the adjusting screws with anti-seize to avoid galling the adjusting screws to the stainless steel base.



©2006

PO Box 81906 Lincoln, NE 68501
402-323-3200 www.speedwaymotors.com

INSTRUCTIONS

300-9000-2

HARDWARE FOR 300-9000 LASER LEVEL

- 1) Thread 1/4" x 20 x 3/4" set screw into bottom of laser. Snug up set screw with wrench taking care not to over tighten.
- 2) Place one washer over set screw and insert set screw through base plate. Install second washer on bottom of base plate and thread on self-locking nut. Carefully tighten nut until laser can be rotated easily by hand, but does not have excessive play.
- 3) Coat the adjusting screws with anti-seize to avoid galling the adjusting screws to the stainless steel base.



©2006

PO Box 81906 Lincoln, NE 68501
402-323-3200 www.speedwaymotors.com

INSTRUCTIONS

300-9000-2

HARDWARE FOR 300-9000 LASER LEVEL

- 1) Thread 1/4" x 20 x 3/4" set screw into bottom of laser. Snug up set screw with wrench taking care not to over tighten.
- 2) Place one washer over set screw and insert set screw through base plate. Install second washer on bottom of base plate and thread on self-locking nut. Carefully tighten nut until laser can be rotated easily by hand, but does not have excessive play.
- 3) Coat the adjusting screws with anti-seize to avoid galling the adjusting screws to the stainless steel base.



©2006

PO Box 81906 Lincoln, NE 68501
402-323-3200 www.speedwaymotors.com

INSTRUCTIONS

300-9000-2

HARDWARE FOR 300-9000 LASER LEVEL

- 1) Thread 1/4" x 20 x 3/4" set screw into bottom of laser. Snug up set screw with wrench taking care not to over tighten.
- 2) Place one washer over set screw and insert set screw through base plate. Install second washer on bottom of base plate and thread on self-locking nut. Carefully tighten nut until laser can be rotated easily by hand, but does not have excessive play.
- 3) Coat the adjusting screws with anti-seize to avoid galling the adjusting screws to the stainless steel base.



©2006

PO Box 81906 Lincoln, NE 68501
402-323-3200 www.speedwaymotors.com