



ASB/SR Adjustable

To adjust, compress the shaft into the shock. Keep light pressure on the shaft and turn the shaft clockwise, until you feel the adjustment tang drop into the slot. As you rotate the shaft clockwise you will feel a total of 9 clicks. These are the same 3 settings repeating. Align the notch on the shaft to the desired valving setting marked on the shock body. Extend the shaft and the shock has set to your desired setting. Please note that it is important that you only turn the shaft clockwise. Rotating the shaft counter clockwise will hurt the shock.

Shocks must be mounted shaft up

Suggested Settings:

Under 3200 lbs:

M - Front

S - Rear

Over 3200 lbs:

F - Front

M - Rear