

INSTALLATION INSTRUCTIONS - INS164

THROTTLE BODY

Part # 1821 - 85mm/18210 - 90mm / 2011-2014 Ford Mustang 5.0L, Ford F-150 5.0L



Special Tools required: No special tools required.



Install Time: Approximately 1 hour.



Difficulty: Easy.



Picture shows part # 18210 with spacer. Part # 1821 does not include or require spacer.



 **MADE IN U.S.A.** 

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

UPDATED LAST: March 2019

FOLLOW THESE INSTRUCTIONS CAREFULLY TO ENSURE CORRECT FITMENT AND OPERATION

STEP 1

Disconnect the negative battery terminal.

STEP 2



Remove the strut tower brace if applicable.

STEP 3



Remove the engine cover by pulling up on it to release its mounting pins from the grommets on the intake manifold.

STEP 4



Disconnect the smaller plastic breather tube from the air inlet tube. You can leave the sound tube connected.

STEP 5

Loosen the clamps on the air inlet tube at the air box and throttle body.

STEP 6



Remove the air inlet tube and set it aside.

🇺🇸 MADE IN U.S.A. 🇺🇸

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

UPDATED LAST: March 2019

FOLLOW THESE INSTRUCTIONS CAREFULLY TO ENSURE CORRECT FITMENT AND OPERATION

STEP 7



Remove the four mounting bolts from the stock throttle body, as you remove the throttle body, flip it to unplug the motor plug on the bottom.

STEP 8

Wipe off the stock rubber throttle body gasket to remove any oil or debris. You will be reusing this gasket.

STEP 9



STEP 9 (CONT.)



Connect the motor plug to the BBK Throttle Body and install onto the intake manifold. Use supplied bolts to secure the throttle body.

STEP 10



Re-install the air inlet tube and reconnect the breather tube. A little WD-40 or light grease on the inside of the tube may help in this process. Tighten the clamps.

STEP 11

Re-install the engine decorative cover, the strut tower brace and reconnect the negative battery terminal.

🇺🇸 MADE IN U.S.A. 🇺🇸

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

UPDATED LAST: March 2019



FOLLOW THESE INSTRUCTIONS CAREFULLY TO ENSURE CORRECT FITMENT AND OPERATION

ENGINE RELEARN PROCESS

Because your vehicles engine is electronically controlled by a computer, some control conditions are maintained by power from the battery. When the battery is disconnected or a new battery is installed, the engine must relearn its idle and fuel trim strategy for optimum drive ability and performance.

STEP 1

With the vehicle at a complete stop, set the parking break

STEP 2

Put the gearshift in P (Park) (automatic transmission or the neutral position (manual transmission), turn of all accessories and start the engine.

STEP 3

Run the engine until it reaches normal operating temperature. Approximately 4-5 minutes.

STEP 4

Allow the engine to idle for at least one minute.

STEP 5

Turn the A/C on and allow the engine to idle for at least one minute.

STEP 6

Drive the vehicle to complete the relearning process.

- The vehicle may need to be driven 10 miles or more to relearn the idle and fuel trim strategy.
- If you do not allow the engine to relearn its idle trim, the idle quality of your vehicle may be adversely affected until the idle trim is eventually relearned

 MADE IN U.S.A. 

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

UPDATED LAST: March 2019