



2650-1867-77

## 1962-65 CHEVY NOVA INSTALLATION INSTRUCTIONS FOR 3 1/8" & 2 1/16" GAUGES

Model 7044

1. The bezel that this insert installs into will need to be removed from your vehicle.
2. Place the stock bezel face down & lay the billet aluminum dash insert into it.
3. Attach the insert to the stock bezel using the stock screws along with the 4 provided Z-shaped brackets.
4. Attach the 2 provided L-shaped brackets to the back of the billet dash insert using the 2 provided 10-32 x 1/4" screws. The holes in the stock bezel should line up with the holes on the brackets.
5. Install the 2 turn signal lights. The eraser end of a pencil works well to push these in.
6. Install the gauges.
7. Install the bezel into your vehicle.
8. Wire the gauges (refer to instructions provided by the gauge manufacturer).

866-248-6356

[www.autometer.com](http://www.autometer.com)

2650-1867-77 12/7/15



2650-1867-77

## 1962-65 CHEVY NOVA INSTALLATION INSTRUCTIONS FOR 3 1/8" & 2 1/16" GAUGES

Model 7044

1. The bezel that this insert installs into will need to be removed from your vehicle.
2. Place the stock bezel face down & lay the billet aluminum dash insert into it.
3. Attach the insert to the stock bezel using the stock screws along with the 4 provided Z-shaped brackets.
4. Attach the 2 provided L-shaped brackets to the back of the billet dash insert using the 2 provided 10-32 x 1/4" screws. The holes in the stock bezel should line up with the holes on the brackets.
5. Install the 2 turn signal lights. The eraser end of a pencil works well to push these in.
6. Install the gauges.
7. Install the bezel into your vehicle.
8. Wire the gauges (refer to instructions provided by the gauge manufacturer).

866-248-6356

[www.autometer.com](http://www.autometer.com)

2650-1867-77 12/7/15