



## EDELBROCK UNIVERSAL CARBURETOR CHOKE CABLE

Part #8013

### INSTALLATION INSTRUCTIONS

While this universal choke cable is universal in application and will work with a wide variety of carburetors, these instructions are specific to Edelbrock Performer and AVS series carburetors. Once the knob has been mounted to the dash and the cable fed through the firewall, it should be routed up to the rear of the carburetor while being careful to avoid contact with the throttle and/or kickdown cables, linkages and fuel lines. Insert the wire end into the hole on the choke lever then use a pair of needle-nose pliers to put two 90° bends in the wire on either side of the lever to hold it in place. Insert the cable sheath into the bracket on the carburetor then tighten the screw to hold it in place. Verify smooth operation of the choke cable, then trim off any excess wire from the end.

Part #8013

Rev. 10/09 - AJ/mc

**Edelbrock Corporation • 2700 California St. • Torrance, CA 90503**

**Tech-Line: 1-800-416-8628 • Office-Line: 310-781-2222**



©2009 Edelbrock Corporation  
Brochure #63-8013



## EDELBROCK UNIVERSAL CARBURETOR CHOKE CABLE

Part #8013

### INSTALLATION INSTRUCTIONS

While this universal choke cable is universal in application and will work with a wide variety of carburetors, these instructions are specific to Edelbrock Performer and AVS series carburetors. Once the knob has been mounted to the dash and the cable fed through the firewall, it should be routed up to the rear of the carburetor while being careful to avoid contact with the throttle and/or kickdown cables, linkages and fuel lines. Insert the wire end into the hole on the choke lever then use a pair of needle-nose pliers to put two 90° bends in the wire on either side of the lever to hold it in place. Insert the cable sheath into the bracket on the carburetor then tighten the screw to hold it in place. Verify smooth operation of the choke cable, then trim off any excess wire from the end.

Part #8013

Rev. 10/09 - AJ/mc

**Edelbrock Corporation • 2700 California St. • Torrance, CA 90503**

**Tech-Line: 1-800-416-8628 • Office-Line: 310-781-2222**



©2009 Edelbrock Corporation  
Brochure #63-8013



## EDELBROCK UNIVERSAL CARBURETOR CHOKE CABLE

Part #8013

### INSTALLATION INSTRUCTIONS

While this universal choke cable is universal in application and will work with a wide variety of carburetors, these instructions are specific to Edelbrock Performer and AVS series carburetors. Once the knob has been mounted to the dash and the cable fed through the firewall, it should be routed up to the rear of the carburetor while being careful to avoid contact with the throttle and/or kickdown cables, linkages and fuel lines. Insert the wire end into the hole on the choke lever then use a pair of needle-nose pliers to put two 90° bends in the wire on either side of the lever to hold it in place. Insert the cable sheath into the bracket on the carburetor then tighten the screw to hold it in place. Verify smooth operation of the choke cable, then trim off any excess wire from the end.

Part #8013

Rev. 10/09 - AJ/mc

**Edelbrock Corporation • 2700 California St. • Torrance, CA 90503**

**Tech-Line: 1-800-416-8628 • Office-Line: 310-781-2222**



©2009 Edelbrock Corporation  
Brochure #63-8013



## EDELBROCK UNIVERSAL CARBURETOR CHOKE CABLE

Part #8013

### INSTALLATION INSTRUCTIONS

While this universal choke cable is universal in application and will work with a wide variety of carburetors, these instructions are specific to Edelbrock Performer and AVS series carburetors. Once the knob has been mounted to the dash and the cable fed through the firewall, it should be routed up to the rear of the carburetor while being careful to avoid contact with the throttle and/or kickdown cables, linkages and fuel lines. Insert the wire end into the hole on the choke lever then use a pair of needle-nose pliers to put two 90° bends in the wire on either side of the lever to hold it in place. Insert the cable sheath into the bracket on the carburetor then tighten the screw to hold it in place. Verify smooth operation of the choke cable, then trim off any excess wire from the end.

Part #8013

Rev. 10/09 - AJ/mc

**Edelbrock Corporation • 2700 California St. • Torrance, CA 90503**

**Tech-Line: 1-800-416-8628 • Office-Line: 310-781-2222**



©2009 Edelbrock Corporation  
Brochure #63-8013