

#550-85-B INSTRUCTIONS

Cam Bushing Degree Kit for Chevy - Odd Degree

Color Code:	Gold	1 degree
	Brown	3 degrees
	Blue	5 degrees
	Purple	7 degrees

Use a 13/32" drill bit to re-drill dowel hole in cam gear. Be sure to securely fasten cam gear when drilling to prevent elongating the hole.



©2006

P.O. Box 81906 Lincoln, NE 68501
402-323-3200
www.speedwaymotors.com

#550-85-B INSTRUCTIONS

Cam Bushing Degree Kit for Chevy - Odd Degree

Color Code:	Gold	1 degree
	Brown	3 degrees
	Blue	5 degrees
	Purple	7 degrees

Use a 13/32" drill bit to re-drill dowel hole in cam gear. Be sure to securely fasten cam gear when drilling to prevent elongating the hole.



©2006

P.O. Box 81906 Lincoln, NE 68501
402-323-3200
www.speedwaymotors.com

#550-85-B INSTRUCTIONS

Cam Bushing Degree Kit for Chevy - Odd Degree

Color Code:	Gold	1 degree
	Brown	3 degrees
	Blue	5 degrees
	Purple	7 degrees

Use a 13/32" drill bit to re-drill dowel hole in cam gear. Be sure to securely fasten cam gear when drilling to prevent elongating the hole.



©2006

P.O. Box 81906 Lincoln, NE 68501
402-323-3200
www.speedwaymotors.com

#550-85-B INSTRUCTIONS

Cam Bushing Degree Kit for Chevy - Odd Degree

Color Code:	Gold	1 degree
	Brown	3 degrees
	Blue	5 degrees
	Purple	7 degrees

Use a 13/32" drill bit to re-drill dowel hole in cam gear. Be sure to securely fasten cam gear when drilling to prevent elongating the hole.



©2006

P.O. Box 81906 Lincoln, NE 68501
402-323-3200
www.speedwaymotors.com

#550-85-B INSTRUCTIONS

Cam Bushing Degree Kit for Chevy - Odd Degree

Color Code:	Gold	1 degree
	Brown	3 degrees
	Blue	5 degrees
	Purple	7 degrees

Use a 13/32" drill bit to re-drill dowel hole in cam gear. Be sure to securely fasten cam gear when drilling to prevent elongating the hole.



©2006

P.O. Box 81906 Lincoln, NE 68501
402-323-3200
www.speedwaymotors.com

#550-85-B INSTRUCTIONS

Cam Bushing Degree Kit for Chevy - Odd Degree

Color Code:	Gold	1 degree
	Brown	3 degrees
	Blue	5 degrees
	Purple	7 degrees

Use a 13/32" drill bit to re-drill dowel hole in cam gear. Be sure to securely fasten cam gear when drilling to prevent elongating the hole.



©2006

P.O. Box 81906 Lincoln, NE 68501
402-323-3200
www.speedwaymotors.com