

INSTRUCTIONS

916-67899 916-67905
916-67906

S/B CHEVY UPPER ALTERNATOR BRACKET

Installation tip: Due to variations in water pump and intake manifold casting, it may be necessary to shim the Upper Alternator Bracket for proper alignment.

The bracket has been jig drilled and hole placement is correct.

©Speedway Motors, Inc. 2006



Speedway Motors, Inc.
Lincoln, NE 402-323-3200
www.speedwaymotors.com

INSTRUCTIONS

916-67899 916-67905
916-67906

S/B CHEVY UPPER ALTERNATOR BRACKET

Installation tip: Due to variations in water pump and intake manifold casting, it may be necessary to shim the Upper Alternator Bracket for proper alignment.

The bracket has been jig drilled and hole placement is correct.

©Speedway Motors, Inc. 2006



Speedway Motors, Inc.
Lincoln, NE 402-323-3200
www.speedwaymotors.com

INSTRUCTIONS

916-67899 916-67905
916-67906

S/B CHEVY UPPER ALTERNATOR BRACKET

Installation tip: Due to variations in water pump and intake manifold casting, it may be necessary to shim the Upper Alternator Bracket for proper alignment.

The bracket has been jig drilled and hole placement is correct.

©Speedway Motors, Inc. 2006



Speedway Motors, Inc.
Lincoln, NE 402-323-3200
www.speedwaymotors.com

INSTRUCTIONS

916-67899 916-67905
916-67906

S/B CHEVY UPPER ALTERNATOR BRACKET

Installation tip: Due to variations in water pump and intake manifold casting, it may be necessary to shim the Upper Alternator Bracket for proper alignment.

The bracket has been jig drilled and hole placement is correct.

©Speedway Motors, Inc. 2006



Speedway Motors, Inc.
Lincoln, NE 402-323-3200
www.speedwaymotors.com