



INSTALLATION INSTRUCTIONS

Boom Mat Hi-Temp Spray Adhesive

KIT CONTENTS:

#010490- (1) 10oz Hi Temp Spray Adhesive

NOTES:

Make sure to spray both surfaces.

TOOLS:

None

SURFACE PREP:

Clean and dry surface thoroughly before spraying. Remove, wax, grease, dirt, etc. before applying.

INSTRUCTIONS:

1. Point valve toward surface and spray from a distance of 6 to 8 inches.
2. Keep the can moving to avoid a build-up on the surface.
3. Only a thin film is required. Avoid over spraying.
4. For a permanent bond spray both surfaces, allow to tack, then bond.
5. AFTER USE: Clear valve of adhesive by turning can upside down and spraying for at least to seconds.

