

2005-2010 Ford Mustang Adjustable Front Sway Bar End Links
Item # 1049



Tools Needed:

18mm Wrench
18mm Socket
10mm Allen Wrench
Torque Wrench (optional)

Removal of the Factory Sway Bar End Links:

1. Begin by jacking the front of car up and place jack stands under the front subframe to leave suspension unloaded.
2. Remove front tire & wheel one side at a time.
3. Remove the factory sway bar end link on the top using the 18mm Socket. Then remove the lower end link nut using the 18mm Wrench.

Installing the New Adjustable Sway Bar Endlinks (1049)

1. Using the hardware that is included in the kit. Starting with the top rod end insert the M12x70mm Allen Bolt from the rear (threads facing towards you).
2. Make sure the aluminum spacer that is included in the kit as well is inserted between the rod end and the factory mounting location with the flat part of the bushing against the mount and the tapered part of the bushing in the rod end to allow the end link to articulate.
3. Last procedure for this side is to install the washer and nylon lock nut that is included in the kit. Tighten or torque down to specs (60-70 ft lbs).
4. Repeat ALL Steps on the other side.

Item # 1049

05-10 Ford Mustang Front End Links

UMI Performance Inc.
Made in Pennsylvania, USA