

2005-2014 Ford Mustang Front Sway Bar Attachment Plates
P/N 1070



Box Contents

Qty	Part #	Description
2	1070	Front Sway Bar Plates
4	1000103	M10 x 25mm Bolt
1	1070 Install Instructions	1070 Install Instructions

Notes: Before installation, verify box contents are correct and read through instructions completely.

Always ensure proper support when working under a vehicle. Use approved jack stands when using a floor jack as well as proper technique for securing your car while on a drive-on lift.

Tools required:

SAE wrenches and sockets
Screwdriver

Installation

1. Raise car to a comfortable working height using the method of your choice. Follow applicable safety procedures.
2. Removal and installation is easiest with the front wheels removed.
3. Starting with the driver side, locate the existing front sway bar and the sway bar bushings.
4. Remove the two nuts holding the sway bar bushing down (See Figure 2).
5. Once the nuts are removed, each of the existing bolts can be pushed up and pulled out to remove them from the frame. There is a slot with a wide opening that the bolt must slip through.
6. Once the factory bolts are removed, insert a #1070 plate into the slim opening of the frame where the sway bar mounts (Be sure to face the weld nuts to the front of the car).
7. The #1070 plate can only be inserted from the top into the slim opening of the frame.
8. Once inserted, use a screwdriver to jiggle the plate until it falls to the bottom of the slot (see Figure 3).
9. Align the sway bar bracket, the hole in the frame, and the #1070 plate so that the supplied 10mm bolt can be threaded onto the weld-nut (See Figure 5).
10. Once both bolts have begun threading into the weld nuts, tighten them to approximately 37 ft-lbs (or moderately tight with hand tools). **DO NOT OVER-TORQUE!**
11. Repeat steps 4-10 for the passenger side bracket.
12. Installation is complete.



Figure 1) View of the front sway bar bracket



Figure 2) Removing nuts (UMI Aluminum Sway Bar Bracket)



Figure 3) Persuading the plate to drop down



Figure 4) Plate has dropped



Figure 5) Aligning the plate and inserting the bolt



509 Hemlock St
Philipsburg, PA 16866
Ph- 814.343.6315 Fax- 814.343.6318

Installation Instructions

support@umiperformance.com
www.umiperformance.com

DISCLAIMER OF WARRANTY

THE PURCHASER ACCEPTS ALL RESPONSIBILITY FOR THE FINAL USE OF THE PRODUCTS PURCHASED AND SHALL HOLD UMI PERFORMANCE INCORPORATED AND ITS REPRESENTATIVES HARMLESS IN ANY LEGAL PROCEEDING ARISING FROM THE USE OF SUCH PRODUCTS.

UMI PERFORMANCE INCORPORATED DOES NOT WARRANT, GUARANTEE, OR MAKE ANY REPRESENTATION REGARDING THE USE, OR THE RESULT OF THE USE OF ANY PERFORMANCE PRODUCT MANUFACTURED OR DISTRIBUTED BY UMI PERFORMANCE INCORPORATED. PURCHASER ASSUMES THE ENTIRE RISK AS THE RESULT AND PERFORMANCE OBTAINED FROM THE INSTALLATION AND USE OF SAID PERFORMANCE PRODUCTS. UMI PERFORMANCE INCORPORATED ASSUMES NO RESPONSIBILITY FOR AND HEREBY DISCLAIMS ALL WARRANTIES, ORAL OR WRITTEN, EXPRESS OR IMPLIED INCLUDING WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY AND OF FITNESS FOR A PARTICULAR PURPOSE.

ALL PARTS ARE WARRANTED TO BE FREE OF DEFECT AT THE TIME OF PURCHASE. WARRANTY IS ONLY EXTENDED TO REPLACEMENT OF PARTS FROM UMI PERFORMANCE INCORPORATED AND DOES NOT COVER LABOR, TOWING OR ANY OTHER DIRECT OR INDIRECT COST. UMI PERFORMANCE INCORPORATED IS NOT RESPONSIBLE FOR ANY CONSEQUENTIAL DAMAGE, EXPENSE OR INJURY ARISING FROM THE USE, MISUSE OR IMPROPER INSTALLATION OF ANY PRODUCT MANUFACTURED AND/OR SOLD BY UMI PERFORMANCE INCORPORATED.

Item # 1070

05 - 14 Ford Mustang Sway bar Attachment Plates

UMI Performance Inc.
Made in Philipsburg, PA - USA