



509 Hemlock St
Philipsburg, PA 16866
Ph- 814.343.6315 Fax- 814.343.6318
Installation Instructions
support@umiperformance.com
www.umiperformance.com

UMI Short Stick- 1979-2004 Ford Mustang 5-Speed
Item # 1200

Note: Handle is designed to fit stock and *most* aftermarket shifter bases

1. Locate shift knob, remove knob by turning counter clockwise. Knob may be hard to remove the first time.
2. Remove leather shifter boot. Be very CAREFUL not to damage boot or mounting tabs.
3. Using a 13mm wrench locate the (2) bolts on the right side of the handle. Remove bolts and pull handle up and off the base.
4. Install the UMI short stick on the left side of the shifter, towards the driver's seat and the threads faced back. Use the (2) supplied bolts and lock washers to attach handle.
5. We highly recommend a small amount of Blue Loctite 242 thread lock be placed on the bolts to keep them from breaking loose.
6. Reinstall the leather shifter boot and shift knob. If shift knob will not tighten in correct position, place Teflon tape on the threads. This will allow for a tighter fit and allow desired position of shifter knob.

Thank you and Please Visit us on the web at www.umiperformance.com

Item # 1200

1979 - 2004 Ford Mustang Short Stick

UMI Performance Inc.
Made in Pennsylvania, USA