

On-Car Adjustable Lower Control Arms w/ Rod ends
Item # 2013



Box Contents:

- (1) Installation Instruction Sheet
- (2) On-Car Adjustable Lower Control Arms
- (2) Rod ends (Assembled, Mounted)
- (4) Polyurethane Bushings (2 per arm, Mounted)
- (2) Steel Sleeves (Mounted)
- (4) Grease Fittings (Mounted)
- (1) Packet Formula 5 Prelube (#9.11108)

Applications:

- * 1982 – 2002 Chevrolet Camaro
- * 1982 – 2002 Pontiac Firebird

1. Before installation, verify box contents are correct and read through instructions completely.
2. On a solid, level surface, jack up the rear of the vehicle to a good working height, making sure both wheels are off of the ground, and secure with (2) jack stands under the frame, one on each side. **Do NOT support vehicle by the rear axle.**

NOTE: Install control arms one side at a time. Removing both control arms will allow the rear axle to shift forward, in turn, making the installation more difficult.

3. Pick a starting side and then using 18mm wrenches/socket, remove both front and rear control arm bolts. Retain bolts for future use. Remove the stock control arm and set aside.
4. Locate the UMI lower control arm and place it on top of the stock control arm to verify that it is set to the factory length before installing.
5. Once the length is verified with the stock arm, prelube the exterior surfaces of the polyurethane bushings with the supplied prelube packet. Position the lower control arm so that the Rod end is mounted to the rear axle, the grease fittings are angled toward the ground and then secure loosely with the bolts retained in step #3. **Do NOT tighten at this time.**

Thank you for Putting Your Trust in A UMI Performance Product!

www.umiperformance.com



509 Hemlock St
Philipsburg, PA 16866
Ph- 814.343.6315 Fax- 814.343.6318
Installation Instructions
support@umiperformance.com
www.umiperformance.com

6. Repeat steps #3 - #5 on opposite side.
7. Lift the rear of the vehicle with a floor jack and re-position the jack stands under the rear axle. Lower the rear of the car on to the jack stands positioned at the axle. This will load the rear suspension.
8. At this time, tighten ALL (4) lower control arm mounting bolts and lube each arm with 1 – 2 pumps of grease only. Recommended torque specification on lower control arm is 72 ft lbs.
9. Lower rear of vehicle to the ground. Installation is complete.

Adjusting your control arms – UMI's adjustable control arms can be adjusted while on the vehicle. To adjust, loosen both jam nuts first. Then, using a 1" wrench, turn the adjuster to extend or shorten length of the control arm. Once ideal setting is achieved, tighten both jam nuts. Be sure to check the jam nuts regularly as they may work loose over time. If one should come loose, simply re-tighten.

Item # 2013

On-Car Adjustable Lower Control Arm w/ Rod ends

UMI Performance Inc.
Made in Pennsylvania, USA

Thank you for Putting Your Trust in A UMI Performance Product!

www.umiperformance.com