



509 Hemlock St
Philipsburg, PA 16866
Ph- 814.343.6315 Fax- 814.343.6318
Installation Instructions
support@umiperformance.com
www.umiperformance.com

1993-2002 GM F-Body Drive Shaft Safety Loop- Long Tube Headers
Item # 2025



1. Jack up rear of vehicle to a good working height, make sure both rear wheels are off the ground. Place (2) jack stands under the rear end keeping the suspension loaded.
2. Locate the factory tunnel brace and remove (4) bolts attaching tunnel brace to the chassis of the car.
3. Remove all (4) rear u-joint bolts and drop rear of driveshaft down enough to slide the driveshaft loop over it.
4. Using the new supplied hardware attach driveshaft loop into original position of the factory tunnel brace. Do not tighten.
5. Raise the driveshaft and reinstall (4) u-joint bolts and tighten.
6. Using the adjustment slots provided in the base of the driveshaft loop position the loop so there is equal amount of room for the floor pan, torque arm, driveshaft and exhaust.
7. Tighten driveshaft loop into place and lower car to ground.

Thank you for putting your trust in a UMI Performance Product!
www.umiperformance.com

Item # 2025

93-02 GM F-Body Drive Shaft Loop

UMI Performance Inc.
Made in Pennsylvania, USA