

93-02 GM F-body Front Coil over Brackets
Item # 2048

IMPORTANT:

If these brackets were bought as part of a shocks and springs kit, please use instructions included with those and disregard these 2048 instructions



IMPORTANT NOTES

UMI is not responsible for failure due to misuse, mis-installation, shock bottoming, etc.

UMI is not responsible for fitment issues when using other companies' components such as sway bars, A-Arms, etc. The 2048 kit fits UMI 35mm and factory sway bar as well as A-arms with the factory shock bolt location

Please follow all applicable safety practices when working on a raised vehicle such as proper use of jack stands and safety glasses, and care when lifting heavy objects.

Thank you for Putting Your Trust in A UMI Performance Product!

www.umiperformance.com

Installation Procedure:

1. Begin by removing front shocks and springs. Be sure to support vehicle in a safe manner.
2. Separate spindle from upper ball joint.
3. Remove bolts from the top of the strut mount from the engine bay. Driver's side will require loosening and moving the brake booster to access some bolt heads.
4. Once all (4) bolts/nuts are removed from the strut mount, remove the bolts holding the lower shock mount.
5. Remove shock and upper control arm mount/strut mount.
6. Remove the shock from the upper strut mount. Use of cutting wheel or penetrating oil likely required.
7. Locate UMI upper mount and orient as shown in Figure 1. Mount with tabs on bottom, 1/4 inch washer in the hole of the upper control arm mount, and 1/8" washer on top to sandwich upper control arm mount.
 - a. NOTE: If the upper control arm mount is corroded, and the lip is deteriorated, the 1/4" washer will prove to be too thick. Factory upper control arm mount should be replaced if the 1/4" washer proves to be too thick. The idea is to clamp onto the upper control arm mount, and the 1/4" washer takes up the space to allow this clamping force.
8. Tighten this system to approximately 55 ft/lbs maintaining the desired tab orientation. If the clamp spins after tightening at this torque, upper control arm mount needs replaced.
9. Align upper control arm in the wheel well and use the supplied M10x35mm bolts and nuts to install. Once fully installed torque all (4) M10 bolts to approximately 55ft/lbs.
10. The upper mount is now installed.
11. Install lower jam nut onto shock by threading down to the bottom. Lip should face up.
12. Install main nut onto shock and thread down to the jam nut.
13. Install washer, bearing and washer (optional).
14. Lubricate threads on shock body with anti-seize.
15. Slide spring down onto shock and install coil over hat.
16. Align coil over shock with the new UMI upper mount. Slide 1/2" bolt through with (2) washers per bolt.
17. Tighten upper shock bolt and locking nut to 60 ft-lb.
18. Complete the installation by installing the factory lower bolts through the shock and lower A-arm.
19. Repeat steps 1-18 for opposite side. Adjust spring perch nut for desired ride height. Align vehicle upon completed installation for optimal handling and steering.

Thank you for Putting Your Trust in A UMI Performance Product!

www.umiperformance.com

Figure 1 – Washer orientation



Figure 2 – Final assembly



DISCLAIMER OF WARRANTY

THE PURCHASER ACCEPTS ALL RESPONSIBILITY FOR THE FINAL USE OF THE PRODUCTS PURCHASED AND SHALL HOLD UMI PERFORMANCE INCORPORATED AND ITS REPRESENTATIVES HARMLESS IN ANY LEGAL PROCEEDING ARISING FROM THE USE OF SUCH PRODUCTS.

UMI PERFORMANCE INCORPORATED DOES NOT WARRANT, GUARANTEE, OR MAKE ANY REPRESENTATION REGARDING THE USE, OR THE RESULT OF THE USE OF ANY PERFORMANCE PRODUCT MANUFACTURED OR DISTRIBUTED BY UMI PERFORMANCE INCORPORATED. PURCHASER ASSUMES THE ENTIRE RISK AS THE RESULT AND PERFORMANCE OBTAINED FROM THE INSTALLATION AND USE OF SAID PERFORMANCE PRODUCTS. UMI PERFORMANCE INCORPORATED ASSUMES NO RESPONSIBILITY FOR AND HEREBY DISCLAIMS ALL WARRANTIES, ORAL OR WRITTEN, EXPRESS OR IMPLIED INCLUDING WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY AND OF FITNESS FOR A PARTICULAR PURPOSE.

ALL PARTS ARE WARRANTED TO BE FREE OF DEFECT AT THE TIME OF PURCHASE. WARRANTY IS ONLY EXTENDED TO REPLACEMENT OF PARTS FROM UMI PERFORMANCE INCORPORATED AND DOES NOT COVER LABOR, TOWING OR ANY OTHER DIRECT OR INDIRECT COST. UMI PERFORMANCE INCORPORATED IS NOT RESPONSIBLE FOR ANY CONSEQUENTIAL DAMAGE, EXPENSE OR INJURY ARISING FROM THE USE, MISUSE OR IMPROPER INSTALLATION OF ANY PRODUCT MANUFACTURED AND/OR SOLD BY UMI PERFORMANCE INCORPORATED.



Thank you for Putting Your Trust in A UMI Performance Product!

www.umiperformance.com



509 Hemlock St
Philipsburg, PA 16866
Ph- 814.343.6315 Fax- 814.343.6318
Installation Instructions
support@umiperformance.com
www.umiperformance.com

This page left blank for notes taken during assembly.

Item # 2048

1993-2002 GM F-body Front Coilover kit
UMI Performance, Inc.
Manufactured in Philipsburg, PA-USA

Thank you for Putting Your Trust in A UMI Performance Product!
www.umiperformance.com