

**1993-2002 GM F-Body Adjustable Upper A-Arms**  
Item # 2310



Box Contents

Qty	Part #	Description
1	2310 Driver	Front Upper Driver A-Arm
1	2310 Passenger	Front Upper Passenger A-Arm
4	KMX10	Rod Ends
8	2310D	Aluminum Rod End Bushings
2	0022	Ball Joint Kits
1	2310 Install Instructions	2310 Install Instructions

**Notes:**

Before installation, verify box contents are correct and read through instructions completely. Always ensure proper support when working under a vehicle. Use approved jack stands when using a floor jack as well as proper technique for securing your car while on a drive-on lift.

**Tools required:**

SAE wrenches and sockets  
Ball Joint Separator

**\*\*\*\*\*WARNING: PLEASE READ\*\*\*\*\***  
**ONLY** tighten the ball joints if the A-arm is installed in the mounting bracket. If the A-arm is not installed tightening the ball joint may cause the A-arm to bow slightly.

## Installation

- 1.** Jack up front of vehicle and place jack stands under vehicle frame. Do not support vehicle using A-Arms.
- 2.** Begin with one side and remove wheel. Note: This installation may be performed easiest with brake assembly and rotor removed. This can be completed now.
- 3.** Locate upper ball joint, remove cotter pin and loosen nut. Do not remove nut.
- 4.** Separate upper ball joint from steering knuckle using a ball joint separator.
- 5.** From inside the engine compartment loosen but do not remove the (4) shock tower bolts. Driver's side may require brake lines to be loosened and moved.
- 6.** Now remove the nut from the upper ball joint, remove the (4) shock tower bolts from the engine compartment and remove upper A-Arm assembly from vehicle.
- 7.** There are (2) options for upper ball joints, the stock ball joint can be removed and reused or purchase (2) new ball joints to install (Recommended). If reusing your stock ball joints you must grind the rivets off the stock A-Arm and use new hardware to install them to the new A-Arms. New ball joints will come supplied with the correct bolts and will bolt directly to the new A-Arm. When purchasing new upper ball joints purchasing them for any 93-02 Camaro/Firebird.
- 8.** Remove the stock A-Arm from the mounting plate. Locate a new A-Arm and place in the location the factory A-Arm was removed and tighten bolts. The ball joint mounting plate will be facing in an upward angle. Make sure the correct A-Arm is installed on the correct side!  
**Use Image 1 below for correct A-Arm direction.**
- 9.** Place A-Arm assembly with new A-Arm into the vehicle. Snug the (4) bolts from inside the engine compartment to assembly in place.
- 10.** Reinstall upper ball joint into steering knuckle using ball joint nut and cotter pin, tighten nut. **Do not forget cotter pin.**
- 11.** Move to Step 7 in above directions and continue install on other side.

**Image 1-** Picture shows passenger side, to the right is the front of the vehicle and to the left is the rear of the vehicle. To install upper A-Arm place the curve of the A-Arm towards the front of the vehicle, grease fittings down and ball joint angled up.



Only tighten ball joint nuts when the arm is attached to the mount in the wheel well.



509 Hemlock St  
Philipsburg, PA 16866  
Ph- 814.343.6315 Fax- 814.343.6318  
**Installation Instructions**  
support@umiperformance.com  
www.umiperformance.com

#### DISCLAIMER OF WARRANTY

THE PURCHASER ACCEPTS ALL RESPONSIBILITY FOR THE FINAL USE OF THE PRODUCTS PURCHASED AND SHALL HOLD UMI PERFORMANCE INCORPORATED AND ITS REPRESENTATIVES HARMLESS IN ANY LEGAL PROCEEDING ARISING FROM THE USE OF SUCH PRODUCTS.

UMI PERFORMANCE INCORPORATED DOES NOT WARRANT, GUARANTEE, OR MAKE ANY REPRESENTATION REGARDING THE USE, OR THE RESULT OF THE USE OF ANY PERFORMANCE PRODUCT MANUFACTURED OR DISTRIBUTED BY UMI PERFORMANCE INCORPORATED. PURCHASER ASSUMES THE ENTIRE RISK AS THE RESULT AND PERFORMANCE OBTAINED FROM THE INSTALLATION AND USE OF SAID PERFORMANCE PRODUCTS. UMI PERFORMANCE INCORPORATED ASSUMES NO RESPONSIBILITY FOR AND HEREBY DISCLAIMS ALL WARRANTIES, ORAL OR WRITTEN, EXPRESS OR IMPLIED INCLUDING WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY AND OF FITNESS FOR A PARTICULAR PURPOSE.

ALL PARTS ARE WARRANTED TO BE FREE OF DEFECT AT THE TIME OF PURCHASE. WARRANTY IS ONLY EXTENDED TO REPLACEMENT OF PARTS FROM UMI PERFORMANCE INCORPORATED AND DOES NOT COVER LABOR, TOWING OR ANY OTHER DIRECT OR INDIRECT COST. UMI PERFORMANCE INCORPORATED IS NOT RESPONSIBLE FOR ANY CONSEQUENTIAL DAMAGE, EXPENSE OR INJURY ARISING FROM THE USE, MISUSE OR IMPROPER INSTALLATION OF ANY PRODUCT MANUFACTURED AND/OR SOLD BY UMI PERFORMANCE INCORPORATED.

### **Item # 2310**

93-02 GM F-Body Front Upper A-Arms

UMI Performance Inc.  
Made in Pennsylvania, USA