

Drive Shaft Tunnel Brace
Item # 2500



Box Contents:

- (1) Installation Instruction Sheet
- (1) Drive Shaft Tunnel Brace

Applications:

- * 2008 – 2009 Pontiac G8 (All Models)
- * 2010 – 2011 Chevrolet Camaro

1. Before installation, verify box contents are correct and read through instructions completely.
2. On a solid, level surface, jack up the vehicle to a good working height to access the drive shaft tunnel brace, and secure with (2) jack stands under the frame, one on each side. **Do NOT support vehicle by the jack alone.**
3. Locate the stock tunnel brace and remove (4) 15mm bolts. Retain bolts for future use.
4. Position the UMI drive shaft tunnel brace into place. Use hardware retained in step #3 to secure the tunnel brace to the vehicle. Torque bolts to 48 ft/lbs.
5. Lower vehicle to the ground. Installation is complete.

Thank you for Putting Your Trust in A UMI Performance Product!

www.umiperformance.com



691 Woodland-Bigler Highway P.O. Box 495 Bigler, Pa 16825

Installation Instructions

Phone: 814.857.5400 Email: support@umiperformance.com

Item # 2500

Drive Shaft Tunnel Brace

UMI Performance Inc.
Made in Pennsylvania, USA

Thank you for Putting Your Trust in A UMI Performance Product!

www.umiperformance.com