



Please read before installing your new Edelbrock product

Catalog number:4240

Model: Small-Block Chevrolet

Installation: Your new cover comes with 8" diameter timing cover tab, Allen bolts and washers, dampener seal, pan seal, block gasket, and two special water pump gaskets (gaskets give additional clearance from water pump to cover.) Make sure dampener is clean and free of defects on seal area and lubricate with engine oil prior to assembly. Make sure water pump does not come in contact with cover on assembly.