

**WATER PUMP REPLACEMENT GASKET KIT**  
**For Edelbrock Water Pumps ONLY**  
**Catalog #7251, 7252, 7253, 7254, 7257, 7258**  
**INSTALLATION INSTRUCTIONS**

**PLEASE** study these instructions carefully before beginning this installation. Most installations can be accomplished with common tools and procedures. However, you should be familiar with and comfortable working on your vehicle. If you do not feel comfortable performing this installation, it is recommended to have the installation completed by a qualified mechanic. If you have any questions, please call our **Technical Hotline at: 1-800-416-8628**, 7:00 am - 5:00 pm, Pacific Standard Time, Monday through Friday or e-mail us at **Edelbrock@Edelbrock.com**.

**IMPORTANT NOTE: Proper installation is the responsibility of the installer. Improper installation will void your warranty and may result in poor performance and engine or vehicle damage.**

**DESCRIPTION:** This kit includes the gasket(s) necessary for the reinstallation of your Edelbrock high performance water pump. Each of these kits has been designed to work with several pumps and will include at least one extra gasket that will not be needed for a given application. Compare the new gaskets to the mounting flange of the block, timing cover, or pump to determine the correct application, or contact our technical support division for further assistance.

**Edelbrock Corporation • 2700 California St. • Torrance, CA 90503**  
**Tech Line: 1-800-416-8628 • E-Mail: Edelbrock@Edelbrock.com**

Catalog #7521, 7522, 7523, 7524, 7527, 7528  
Rev. 11/07 - AJ/mc

Gasket Kit #	Engine Family	Compatible Pumps
<b>7251</b>	Small Block Chevy	8810, 8811, 8812, 8815, 8820, 8821, 8822, 8825, 8881, 8882, 8891, 8892, 88102, 88104, 88112, 88114, 88812, 88814
<b>7252</b>	Big Block Chevy	8850, 8851, 8852, 8853, 8854, 8858, 8860, 8861, 8862, 8863, 8864, 88502, 88504, 88512, 88514
<b>7253</b>	Small Block Ford (standard rotation)	8841, 8842, 8843, 8844, 8846, 8847, 8848, 8849, 88412, 88414
<b>7254</b>	Small Block Ford (reverse rotation)	8045, 8046, 8840, 8845
<b>7257</b>	Big & Small Block Chrysler	8814, 8824, 8877, 8887
<b>7258</b>	FE & Big Block Ford	8805, 8835, 8866, 8876

**INSTALLATION NOTES**

Backing plates should only be tightened to 8 ft/lbs to avoid potential damage to the pump housing. A thin layer of Ultra Blue RTV silicone sealant can be applied to both sides of the water pump gaskets to ensure a proper seal is achieved, but is not strictly necessary.

©2007 Edelbrock Corporation  
Brochure #63-7251

**WATER PUMP REPLACEMENT GASKET KIT**  
**For Edelbrock Water Pumps ONLY**  
**Catalog #7251, 7252, 7253, 7254, 7257, 7258**  
**INSTALLATION INSTRUCTIONS**

**PLEASE** study these instructions carefully before beginning this installation. Most installations can be accomplished with common tools and procedures. However, you should be familiar with and comfortable working on your vehicle. If you do not feel comfortable performing this installation, it is recommended to have the installation completed by a qualified mechanic. If you have any questions, please call our **Technical Hotline at: 1-800-416-8628**, 7:00 am - 5:00 pm, Pacific Standard Time, Monday through Friday or e-mail us at **Edelbrock@Edelbrock.com**.

**IMPORTANT NOTE: Proper installation is the responsibility of the installer. Improper installation will void your warranty and may result in poor performance and engine or vehicle damage.**

**DESCRIPTION:** This kit includes the gasket(s) necessary for the reinstallation of your Edelbrock high performance water pump. Each of these kits has been designed to work with several pumps and will include at least one extra gasket that will not be needed for a given application. Compare the new gaskets to the mounting flange of the block, timing cover, or pump to determine the correct application, or contact our technical support division for further assistance.

**Edelbrock Corporation • 2700 California St. • Torrance, CA 90503**  
**Tech Line: 1-800-416-8628 • E-Mail: Edelbrock@Edelbrock.com**

Catalog #7521, 7522, 7523, 7524, 7527, 7528  
Rev. 11/07 - AJ/mc

Gasket Kit #	Engine Family	Compatible Pumps
<b>7251</b>	Small Block Chevy	8810, 8811, 8812, 8815, 8820, 8821, 8822, 8825, 8881, 8882, 8891, 8892, 88102, 88104, 88112, 88114, 88812, 88814
<b>7252</b>	Big Block Chevy	8850, 8851, 8852, 8853, 8854, 8858, 8860, 8861, 8862, 8863, 8864, 88502, 88504, 88512, 88514
<b>7253</b>	Small Block Ford (standard rotation)	8841, 8842, 8843, 8844, 8846, 8847, 8848, 8849, 88412, 88414
<b>7254</b>	Small Block Ford (reverse rotation)	8045, 8046, 8840, 8845
<b>7257</b>	Big & Small Block Chrysler	8814, 8824, 8877, 8887
<b>7258</b>	FE & Big Block Ford	8805, 8835, 8866, 8876

**INSTALLATION NOTES**

Backing plates should only be tightened to 8 ft/lbs to avoid potential damage to the pump housing. A thin layer of Ultra Blue RTV silicone sealant can be applied to both sides of the water pump gaskets to ensure a proper seal is achieved, but is not strictly necessary.

©2007 Edelbrock Corporation  
Brochure #63-7251