



## **EDELBROCK INTAKE MANIFOLD BOLT KIT**

### **Catalog #8529**

### **INSTALLATION SUPPLEMENT**

In addition to the eight (8) 5/16" x 2-1/4" and eight (8) 3/8" x 1.75" bolts supplied in this kit, we have supplied a single (1) 3/8" x 1.5" bolt. This shorter bolt is only intended for use on the #7129 289/302 E-Boss manifold. The passenger side front runner may cause difficulty when installing a full size 3/8" bolt in the adjacent provision, but the shorter bolt should have sufficient clearance. This bolt can be discarded if you are installing the #7183 351W E-Boss manifold. Refer to the manifold installation instructions for further detail, or contact our Technical Support division using the information provided below.

Catalog #8529  
Rev. 6/08 - AJ/mc

**Edelbrock Corporation • 2700 California St. • Torrance, CA 90503**  
**Tech-Line: 1-800-416-8628 • E-Mail: Edelbrock@Edelbrock.com**

©2008 Edelbrock Corporation  
Brochure #63-8529



## **EDELBROCK INTAKE MANIFOLD BOLT KIT**

### **Catalog #8529**

### **INSTALLATION SUPPLEMENT**

In addition to the eight (8) 5/16" x 2-1/4" and eight (8) 3/8" x 1.75" bolts supplied in this kit, we have supplied a single (1) 3/8" x 1.5" bolt. This shorter bolt is only intended for use on the #7129 289/302 E-Boss manifold. The passenger side front runner may cause difficulty when installing a full size 3/8" bolt in the adjacent provision, but the shorter bolt should have sufficient clearance. This bolt can be discarded if you are installing the #7183 351W E-Boss manifold. Refer to the manifold installation instructions for further detail, or contact our Technical Support division using the information provided below.

Catalog #8529  
Rev. 6/08 - AJ/mc

**Edelbrock Corporation • 2700 California St. • Torrance, CA 90503**  
**Tech-Line: 1-800-416-8628 • E-Mail: Edelbrock@Edelbrock.com**

©2008 Edelbrock Corporation  
Brochure #63-8529



## **EDELBROCK INTAKE MANIFOLD BOLT KIT**

### **Catalog #8529**

### **INSTALLATION SUPPLEMENT**

In addition to the eight (8) 5/16" x 2-1/4" and eight (8) 3/8" x 1.75" bolts supplied in this kit, we have supplied a single (1) 3/8" x 1.5" bolt. This shorter bolt is only intended for use on the #7129 289/302 E-Boss manifold. The passenger side front runner may cause difficulty when installing a full size 3/8" bolt in the adjacent provision, but the shorter bolt should have sufficient clearance. This bolt can be discarded if you are installing the #7183 351W E-Boss manifold. Refer to the manifold installation instructions for further detail, or contact our Technical Support division using the information provided below.

Catalog #8529  
Rev. 6/08 - AJ/mc

**Edelbrock Corporation • 2700 California St. • Torrance, CA 90503**  
**Tech-Line: 1-800-416-8628 • E-Mail: Edelbrock@Edelbrock.com**

©2008 Edelbrock Corporation  
Brochure #63-8529



## **EDELBROCK INTAKE MANIFOLD BOLT KIT**

### **Catalog #8529**

### **INSTALLATION SUPPLEMENT**

In addition to the eight (8) 5/16" x 2-1/4" and eight (8) 3/8" x 1.75" bolts supplied in this kit, we have supplied a single (1) 3/8" x 1.5" bolt. This shorter bolt is only intended for use on the #7129 289/302 E-Boss manifold. The passenger side front runner may cause difficulty when installing a full size 3/8" bolt in the adjacent provision, but the shorter bolt should have sufficient clearance. This bolt can be discarded if you are installing the #7183 351W E-Boss manifold. Refer to the manifold installation instructions for further detail, or contact our Technical Support division using the information provided below.

Catalog #8529  
Rev. 6/08 - AJ/mc

**Edelbrock Corporation • 2700 California St. • Torrance, CA 90503**  
**Tech-Line: 1-800-416-8628 • E-Mail: Edelbrock@Edelbrock.com**

©2008 Edelbrock Corporation  
Brochure #63-8529