



FORCE II

409S Stainless Steel

Installation Instructions for:
SYSTEM #817418
2004-2008 FORD F-150 TRUCKS
V8 • ALL WHEELBASES

06/03/11

Removal:

- 1) Disconnect the negative side of the battery cable. Raise the vehicle up on a hoist or rack to working height. If you do not have access to a hoist or rack raise the vehicle and support securely with jack stands.
- 2) Support the muffler with a stand. Separate the three rubber hangers on the muffler and tailpipe from the rubber mounts on the vehicle. (A lubricant of some kind will make this easier.)
- 3) Using a hacksaw or sawsall, cut the tailpipe off where it exits the muffler. Remove the tailpipe and set aside.
- 4) Remove the band clamp that secures the factory inlet pipe to the converter Y-pipe. Remove the inlet pipe/muffler assembly and set aside.

Installation:

- 1) Before installing anything, prep the clamps supplied in the hardware kit by removing the nuts, and applying a thick lubricant such as white grease or anti-seize to the threads.
- 2) Based on production variations this is a list of cab designs, bed lengths and wheel bases to cut your new inlet pipe **#26242S** to fit your application. Double check all measurements before cutting your inlet pipe:

Regular Cab

6.5' Bed – Trim 19.50" off the rear of the inlet pipe.

8.0' Bed – Trim 1.0" off the rear of the inlet pipe.

Super Cab

5.5' Bed – Trim 13.0" off the rear of the pipe.

6.5' Bed – Trim 1.0" off the rear of the pipe.

8.0' Bed – No trim on **#26242S**, add extension to pipe **#26244S** and trim off 2.25".

Super Crew

5.5' Bed – Trim 7.0" off the rear of inlet pipe.

6.5' Bed – No trim on **#26242S**, add extension to pipe **#26244S** and trim off 14.75".

- 3) Slide a 2 1/2" clamp **#MC250BS** over the reduced end of the inlet pipe. Place the inlet pipe onto the back of the existing OEM head pipe (by lining up the notch). Tighten enough to hold in place, but still allow for adjustment.

- 4) Slide the inlet hanger **#292HA** over the back of the inlet pipe and insert the hanger into the factory rubber mount. Tighten both clamps enough to hold, but still allow for adjustment.
- 5) Place a 3" clamp onto the inlet neck of the muffler, and then slip the muffler onto the inlet pipe. Tighten the clamp just enough to hold in position.
- 6) Slide a 2 1/2" clamp **#MC250BS** onto each muffler outlet neck. Place the right side tailpipe **#16503S** into position over the axle and into the right side muffler outlet. Place the tailpipe hanger rod into the factory rubber mount. Tighten the clamp enough to hold, but still allow for adjustment.
- 7) Mount the left hanger bracket **#211HA** to the frame on the driver's side of the vehicle. There are factory holes (one round, one square) on the bottom of the frame next to spare tire. Place the 5/16" bolt and flat washer up into the square hole and back down through the round hole. Using a flexible head magnet to help guide the bolt makes this process *much* easier. Now place the bracket in position and install a flat washer, lock washer and nut. Using two 1/2" wrenches tighten firmly (do not overtighten). Once the hanger bracket is secured, slide on rubber hanger **#HA168**.
- 8) Place the front section of the left side tailpipe **#16444S** into the left side of the muffler outlet and insert hanger welded to pipe into the factory rubber mount. Tighten the clamp enough to hold, but still allow for adjustment. Place another 2 1/2" clamp onto the rear (expanded) end of the pipe and tighten enough to hold in place, but still allow for adjustment.
- 9) Place the left rear tailpipe section **#16506S** into the expanded connection of the front section. Connect the hanger rod to the rubber mount installed in Step 7. Tighten the clamp down enough to hold the pipe in place, but still allow for adjustment.
- 10) Slide either the side exit pipe **#16317S** or rear exit pipe **#16397S** onto the ends of both over axle pipes. Place a 2 1/2" clamp onto these slip-fit connections and tighten enough to hold, but still allow for adjustment. Place the two stainless tips **#ST396** onto the exit pipes and tighten the pinch bolts enough to hold but still allow for adjustment. Rotate the exit pipe and tip to the desired distance from the fender or bumper so that the angle cut on the tips are in the desired location.
- 11) Adjust the position of all pipes and muffler to provide a satisfactory fit. A minimum of 3/4" clearance around all parts of the system must be maintained; while also keeping suspension travel and vibration in mind. After adjustments have been made, you may now securely tighten all clamps.
- 12) After the system is secure, slide the 7/16" hanger keeper onto the left tailpipe hangers. This keeper will prevent the hanger rods from slipping out of the rubber mount.
- 13) For a cleaner and more secure installation, we recommend welding all slip-fit connections.

PACKING LIST

<u>Qty</u>	<u>Description</u>	<u>Part#</u>	
1	Inlet Pipe	26242S	
1	Extension pipe	26244S	
1	Muffler	8530552-Z	
1	Right Tailpipe	16503S	
1	Left Tailpipe, Front	16444S	
1	Left Tailpipe, Rear	16506S	
2	Side Exit Pipes	16317S	
2	Rear Exit Pipes	16397S	
2	Stainless Tip	ST396	
1	Parts Kit	PK531	
6	2-1/2" Clamp		MC250BS
2	3" Clamp		MC300BS
1	Rubber Hanger		HA168
1	Clamp Hanger		292HA
1	Frame Hanger, Rear		211HA
1	5/16" Nut		HW102
1	5/16" x 1 1/4" Bolt		HW205
2	5/16" Flat Washer		HW302
1	5/16" Lock Washer		HW308
2	7/16" Hanger Keeper		HW502



FORCE II™

409S Stainless Steel

Installation diagram for:
SYSTEM #817418
2004-2008 FORD F-150 TRUCKS
V8 • ALL WHEELBASES

