



**1967-69 GM F-BODY 2-1/8"
BIG BLOCK CHEVY STAINLESS STEEL FULL-LENGTH HEADERS
BH13183
Installation Instructions**



Thank you for choosing to use BLACKHEART headers on your vehicle. Hooker headers are designed with optimized components and geometry to ensure the highest level of fit and performance. Please read these instructions thoroughly before attempting installation of these components.

PRE-INSTALLATION CONSIDERATIONS:

Check that the hardware package includes the following:

| Qty. | Description |
|------|--------------------------|
| 12 | 3/8-16 x 1" Header Bolts |
| 2 | Gaskets |

If you are missing any hardware, please contact Technical Service at 1-866-464-6553.

NOTE: PLEASE BE AWARE THAT SINCE THESE HEADERS HAVE 2-1/8" PRIMARIES CLEARANCES WITH BE TIGHT. A COMBINATION OF HEAT PROTECTION AND/OR REROUTING OF BRAKE AND FUEL LINES MAY BE NECESSARY. IT WILL ALSO BE NECESSARY TO USE A COMBINATION OF SPARK PLUG WIRE ENDS AND BOOTS (90° & STRAIGHT) FOR PROPER CLEARANCE AT THE SPARK PLUG. If needed, heat protection and spark plug wire accessories are available at www.holley.com

NOTE: Will not work with factory automatic transmission column shift linkage. Aftermarket automatic transmission column linkage or cable kits such as those offered by Lokar™ and others will have to be used if you wish to maintain a column shifted linkage set-up in your vehicle.

NOTE: Factory style big block frame stands and motor mounts must be used to ensure proper engine locations and header fit.

NOTE: These headers are compatible with the factory manual transmission Z-bar/linkage. Will not work with factory air conditioning.

An automotive lift or a jack and jack stands will be required to safely raise and support the vehicle. **CAUTION! WORK ONLY ON A LEVEL SURFACE. USE JACKS /JACK STANDS OF SUFFICIENT CAPACITY TO LIFT AND SUPPORT YOUR VEHICLE. NEVER WORK UNDER A VEHICLE SUPPORTED BY A FLOOR OR BUMPER JACK.**

INSTALLATION:

1. Disconnect the negative cable from the vehicle battery, if connected.
2. Remove spark plugs and spark plug wires from the engine.
3. Remove the engine oil dipstick tube.
4. Remove the clutch Z-bar linkage from the frame if present.
5. Remove any existing headers/exhaust manifolds from the engine.
6. Using an automotive lift or floor jack, lift the entire vehicle or front of the vehicle a minimum of 36" off the ground.
7. Separate the pitman arm from the steering center link, disconnect the power steering lines (if equipped) and the steering coupling at column, and remove the steering box.
8. Move the driver's side header into position for installation from the bottom of the vehicle. Install the header gasket and start bolts enough to support the header (it should swing freely on the bolts).
9. Reinstall the steering box at this time. Reattach steering coupling, tighten mounting bolts, reattach pitman arm to center link (use new cotter pin), and reconnect power steering lines (if equipped).
10. Tighten the driver's side header bolts at this time (starting in the center, and working outward).
11. Move the passenger's side header into position for installation from the bottom of the vehicle and install it onto the engine using the remaining gasket and header bolts. Tighten bolts (starting in the center and working outward).
12. Verify that there is adequate clearance between fuel/brake lines. It is also recommended that heat insulation material be used on any lines that come in close proximity to the header tubes, or that new fuel/brake lines be created that route the lines further away from the header tubes.
13. Reinstall engine oil dipstick tube, spark plugs/spark plug wires, and clutch Z-bar as needed.
14. Reconnect negative battery cable.

LIMITATION OF LIABILITY – DISCLAIMER:

The regulation of emissions production, noise levels, and safety standards is undertaken by the federal government, each of the fifty state legislatures, and by many local municipalities, towns, and counties.

HOOKER™ makes no warranties of merchantability, of fitness for particular purpose, or that its products are approved for general use, or that its products are approved for general use, or that its products comply with laws, regulations, or ordinances in the state where they may be sold to the ultimate purchaser, the consumer.

Unless expressly stated to the contrary in the catalog, instruction sheet; or price list, the entire risk as to the conformity of any company product in any such state and as to repair should the product prove to be defective or non-conforming, is on the retail purchaser, the buyer, the ultimate consumer, of such product and it is not upon the seller, distributor, or manufacturer.

In this connection, the retail purchaser, the buyer, the ultimate consumer assumes the burden of the entire cost of any and all necessary service, alterations, or repair.

THE FOREGOING STATEMENT LIMITS THE LIABILITY OF THE MANUFACTURER.

California vehicle code, sections 27156 and 38391, prohibits the advertising, offering for sale, or installation of any device, which modifies a vehicle's emission control system, unless exempted, unless otherwise noted. BLACKHEART Headers that have not received an Executive Order (E.O.) exemption from these code sections are not legal for sale or use in California on vehicles originally equipped with catalytic converters, except for racing vehicles, which may never be driven upon a highway. Check with your local authorities to determine if these headers are legal for use in your particular area.

Technical Service: 1-866-464-6553

© 2019 Hooker Headers. All Rights Reserved. Tous Droits Réservés.

199R11809

Date: 4-1-19