



Corporate Office: PerTronix Inc. 440 E. Arrow Highway, San Dimas, California 91773 * Phone 909.599.5955 • FAX 909.599.6424

Installation Instructions and Warranty Information

Dodge Dakota & Ram 5.2/5.9

1940S-1 1992-95

1945S-1 1996-02



The product accompanying this document has been granted a California Air Resources Board (CARB) exemption, an "E.O." number, or is a direct or consolidated replacement part. It is 50-state legal, when installed on the appropriate vehicles per the manufacturer's application guide.

CARB EO # D-57-28

Read all instructions carefully before attempting installation.

Rev. 1 2-28-13 DSL

PerTronix© thanks you for choosing JBA HEADERS, the best fitting, highest quality header on the market. In order to realize the full potential of our good fit, please read and understand these instructions completely prior to starting work.

Check to make sure you received the proper parts for your application. The header number will be stamped on the engine flange. If you are unsure you have received the proper parts call before you start work.

Be sure to work safe! Whenever you work under the vehicle be sure that it is located on level, solid ground and is supported by adequate safety stands! Remember: Hot asphalt will not support most jack stands!

Many factors affect the installation of headers, some of which are broken or aftermarket motor mounts, accidents that impact the configuration of the frame, and/or the installation of different engines or aftermarket cylinder heads.

Attention Customers breaking in new engines: Due to the extreme heat generated during the break-in process, the appearance of the ceramic coating may be altered in certain areas. The protection characteristics and thermal barrier properties of the coating is never compromised. It is recommended that a cast iron manifold or old set of headers be used for this process.

Notice: The coating of these headers can be marred or scratched during installation. If the header needs to be returned and is damaged, you will be charged for recoat.

JBA uses sealing beads on all its headers. We have found that when installed correctly, the raised bead around each port increases the pressure exerted on the gasket directly adjacent to the port and effectively prevents leaking gaskets. It is normal for the flange to be raised off the cylinder head the thickness of the sealing bead. It is important when installing the header, to install all bolts loosely, then tighten evenly to ensure the flat installation of the flange. The torque sequence from one flange to another will vary, but generally every bolt on a header should be first fit snug, starting from the inside of the flange working out, alternating from top to bottom so that the bolt connects the flange to the manifold to the point where they barely touch. Second, using the same inside-out pattern, tighten each bolt until finished. This method will help prevent leakage and will give the user the best possible performance out of their pair of headers.

1. Place vehicle in a location where the floor is solid and flat, with adequate lighting. Do not attempt to work on a hot engine. Heat causes metal to expand and makes removal of fasteners difficult at best. Disconnect the battery cables from the battery. Raise the front of the vehicle to obtain adequate access to the bottom exhaust manifold flanges. Use large-base jack stands to support the vehicle. Do not rely on the jack! Block the tires to prevent the vehicle from rolling off the jack stands.

2. Spray WD-40 or some type of penetrating oil on all accessible fasteners and fittings before attempting to remove them.

3. From underneath the vehicle disconnect the Y-pipe from the exhaust manifold.

4. Begin with the driver's side. Unbolt the four bolts and two nuts that attach the manifold to the head (save the two nuts and washers for re-installation).

5. Using a scraper, remove all carbon deposits and high spots from head surface. At this time apply a high temperature sealer to exhaust pipe flare in order to avoid problems due to lack of space later on in the installation.
6. Slide the new gasket (supplied) over the center studs. You may need to start nuts and washers on center bolts before pressing header to the head.
7. Install the header using supplied hardware.
8. For 1992 –1995 models only begin on the passenger side by removing the bolts attaching the EGR tube to the exhaust manifold. Once the bolts have been removed, slightly loosen the tube at the EGR valve (located on the back of the intake manifold) Do not Remove Tube.
9. For all other models proceed by unbolting the four bolts and two nuts that attach the passenger side manifold to the head (Save the two nuts and washers for re-installation).
10. Using a scraper remove all carbon deposits and high spots from head surface. At this time apply a high temperature sealer to exhaust pipe flare, in order to avoid problems due to lack of space later on in the installation.
11. Slide the new gasket (supplied) over the center studs. You may need to start the nuts and washers on center bolts before pressing header to the head.
12. Once again, install the passenger side header using the supplied hardware..
13. Then apply some silicone to the base fitting of the EGR tube and re-tighten the air tube using the hardware provided.
Note: Due to the design and materials used on the factory Y-pipe, it is common to have the Y-pipe assembly distort from its original shape due to repeated heating and cooling. The heating and cooling of the assembly works as a stress relieving
14. Reconnect the exhaust system to the header using the hardware provided (Note: some 1992-1995 models may require a flare reduction donut for exhaust pipe).
15. Check to make sure there is adequate clearance on plug wires, battery cables, wire looms, brake lines, etc.
16. Re-connect battery cables.
17. Recheck everything!
18. Start the engine and let it warm up. Check for leaks. Shut engine off and let it cool down. Check to make sure all fasteners are tight.
19. All tubular headers require maintenance including periodically checking and retightening of the header

Parts List:

- (1) Driver's Side Header Assembly
- (1) Passenger's Side Header Assembly
- (12) 5/16" x 1" header bolts & lock washers
- (2) Header gaskets (Header to Head flange)
- (4) 3/8" 16 x 2 1/2" Collector Bolts, Nuts & Washers.
- (2) 1/4" x 1 1/4" Air Fitting Bolts, Washers & Lock Nuts. (1995 and older only)
- (1) 1/4" Air Fitting
- (2) Sealing Domes (with air 1940)



440 E. Arrow Hwy.
San Dimas, CA 91773
(909) 599-5955

This vehicle is equipped with:

Dougs Headers # D44XX

JBA Headers # 15XXS, 19XXS

Legal for sale and installation in California

CARB EXECUTIVE ORDER

D-57-19 & D-57-28

WARNING

This label is required to aid in passing the California smog check program. This label must be installed in an underhood location that is readily visible.

LIMITED ONE YEAR WARRANTY

All JBA HEADERS and exhaust products are guaranteed, to the original purchaser, to be free of defects in materials and workmanship for one year. This warranty covers the replacement or repair of the product only and does not cover the cost of removal and installation, customer applied aftermarket coatings or any discoloration or corrosion of finished surfaces.

Damage or product failure resulting from collision, improper installation, off-road use, road hazards, the use of exhaust insulating wrap or like products or rust occurring after installation, is not covered by the warranty. The warranty extends only to the original purchaser.

Should a part become defective it should be returned to the original selling retailer and must be accompanied with the sales receipt. If there is no retailer in your area, call the factory for a return authorization and return your part prepaid to the factory for inspection. PerTronix reserves the rights to replace or repair the alleged defective part and return the part freight collect.

JBA
performance**exhaust** 

