


INSTALLATION INSTRUCTIONS

* Installation Recommendation: JBA recommends in most cases that the vehicle be taken to a reputable exhaust shop.

40-1511
2000-2002 Dodge Durango
4.7L / 5.9L 2/4wd

RECOMMENDED TOOLS:	PARTS LIST:	
	A. Intermediate pipe	1
	B. Muffler	1
	C. Tail pipe	1
	D. Rear muffler hanger clamp	1
	E. Front muffler clamp	1
	F. forward exhaust clamp	1
pry bar		
ratchet		
15mm deep socket		
pair of channel lock pliers		
anti-seize		
spray lubricant or penetrating oil		



TO START:

- 1. Remove and inventory JBA exhaust.
- 2. Disconnect negative battery cable and allow vehicle exhaust to cool.



- 3. With the vehicle raised and properly supported, use the reciprocating saw to cut the weld at the rear of the muffler. Remove the factory tailpipe.

- 4. With factory tail pipe removed, the muffler assembly should slid off.



- 5. With the factory exhaust completely removed, place a muffler clamp (F) over the factory remaining catalytic converter pipe.



- 6. Install new intermediate pipe (A).



- 7. Install hangers attached to intermediate pipe (A) into factory rubber isolators.



- 8. Install exhaust clamp (F).



- 9. Install muffler (B).



- 10. Install exhaust clamp (E) at front of muffler.



- 11. Install hanger clamp (D) at the rear of the muffler.



- 12. Install tailpipe (C).



- 13. Slip tail pipe (C) in rear of muffler (B).



- 14. Install tail pipe hanger into factory rubber isolator.



- 15. Align tail pipe.



- 16. Check to insure there is adequate clearance over the rear axle.

- 17. After installation, it is recommended that all clamps be re-tightened.

- 18. Tack weld all slip connections in three spots.

- 19. Lower the vehicle and reattach the negative battery cable.

- NOTES:
- 1) It may be necessary to loosen and realign the spare tire for proper clearance.
 - 2) All exhaust systems will expand about 1" rearward when exhaust temperatures start to rise.
 - 3) Use Anti-seize on threads of clamps.