



758-


INSTALLATION INSTRUCTIONS FOR FUEL SENDING UNIT
PART# 890, 8240, 1190, 11240

PART LIST

- 1 SENDING UNIT
- 1 RETAINING RING
- 1 GASKET
- 6 1/4X20X1" BOLTS
- 6 WASHERS

TOOLS REQUIRED

- DRILL MOTOR
- 2" HOLE SAW
- 9/32 DRILL BIT
- TWO 7/16 WRENCHES



1. UNBOLT CAP ASSEMBLY AND REMOVE ALL FOAM FROM CELL.
2. SELECT A FLAT SURFACE ON TOP OF CELL, MAKING SURE THERE IS ADEQUATE CLEARANCE (APPROXIMATELY 2") FROM HARDWARE, SIDES OF FUEL CELL AND MOUNT STRAP RECESSES.
3. DRILL 2" HOLE THROUGH CELL WITH HOLE SAW.
4. INSERT SENDING UNIT THROUGH 2" HOLE AND USE AS TEMPLATE FOR DRILLING MOUNTING HOLES. USE THE 9/32" DRILL.
5. REMOVE SENDING UNIT AND THOROUGHLY CLEAN CELL!!!
6. PLACE RUBBER GASKET ONTO TUBE OF SENDING UNIT.
7. PLACE RETAINING RING THROUGH CAP HOLE. INSERT SENDING UNIT TUBE THROUGH DRILLED HOLE IN CELL AND RETAINING RING.
8. LINE UP HOLES IN UNIT AND RETAINING RING AND THREAD 1/4 INCH BOLTS AND WASHERS INTO RING. BE SURE TO ATTACH GROUND WIRE TO ONE OF THE MOUNTING BOLTS.
9. TIGHTEN ALL SIX BOLTS EVENLY UNTIL GASKET EDGE BEGINS TO PROTRUDE. (DO NOT OVERTIGHTEN).
10. REINSTALL FOAM & CAP ASSEMBLY.
11. ATTACH GAUGE WIRE TO THREADED STUD ON TOP OF SENDING UNIT.

SENDER TO GAUGE CROSS REFERENCE

PART # 890 & 1190
 (0/90 OHM)
 0 OHMS=EMPTY
 90 OHMS=FULL

PART # 8240 & 11240
 (240/33 OHMS)
 240 OHMS=EMPTY
 33 OHMS=FULL

PART # 870 & 1170
 (70/10 OHMS)
 70 OHMS=EMPTY
 10 OHMS=FULL

AUTOMETER
 AUTOGAUGE 2316
 Z SERIES 2620
 PERFORMANCE 2511
 SPORT COMP. 3511
 PRO-COMP. 5415

AUTOMETER
 Z-SERIES 2622
 PERFORMANCE 2513
 SPORT COMP 3513
 PRO-COMP 5417

AUTOMETER
 Z-SERIES 2315
 PERFORMANCE 2512
 SPORT COMP 3512

VDO
 COCKPIT 301-030
 COCKPIT (UL) 301-038
 SERIES I 301-303
 COCKPIT ROYALE 301-738
 INDUSTRIAL 301-503
 INDUSTRIAL 301-504
 PRO COCKPIT 301-602

VDO
 COCKPIT 301-029
 SERIES 1 301-302
 COCKPIT ROYALE 301-740
 INDUSTRIAL 301-505
 INDUSTRIAL 301-506
 PRO COCKPIT 301-604

VDO
 COCKPIT 301-032
 COCKPIT ROYALE 301-739

S.W.
 TRACKFORCE P82869
 TRACKFORCE P82889
 DELUXE 82341
 H.D. 248BS

S.W.
 TRACKFORCE P82813
 TRACKFORCE P82833
 TRACKFORCE P82863
 TRACKFORCE P82883
 DELUXE 82303
 DELUXE 82413
 H.D. 284M

S.W.
 TRACKFORCE P82870
 TRACKFORCE P82890
 WORLD WIDE 82727
 DELUXE 82342
 HEAVY DUTY 284BR

NOTE: These are only recommendations to work with JAZ PRODUCTS fuel senders. Many other gauge manufacturers produce gauges that will work. Match the ohms of the sender with ohms of the gauge manufacturer.

WARNING

**SENDER OR RECEIVER MAY BE DAMAGED IF
 HOT WIRE TOUCHES SENDER TERMINAL.**

