



Installation Instructions

Part Number 33-2063-1

This filter fits: **See current K&N catalog for complete listing**

FREE K&N DECAL** To register your warranty, please see us online at knfilters.com/register. **FREE K&N DECAL

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter is a direct replacement for the stock air filter, and no modifications will be required. However the following procedure **MUST** be followed to ensure a proper fit and seal of the K&N Air Filter.

Installation

- 1) Loosen the hose clamp on the intake hose at the airbox and remove the hose from the airbox.
- 2) Remove the old filter.
- 3) Wipe any dirt out of the lid or base. The airbox base must be clean and dry so that the gasket will stick to it.
- 4) Apply the self-sticking gasket around the edge of the filter opening.
- 5) Install the K&N Air Filter.

NOTE: On vehicles that have the air filter mounted vertically it is advisable to slide the filter up into the air box towards the top so when the airbox is closed the filter will not slide completely to the bottom of the box and risk drawing in un-filtered air.

- 6) Re-install the hose onto the airbox and tighten clamp.

These instructions must be followed every time the filter is serviced, otherwise the filter may not seal, and damage to the engine could result.

