



INSTALLATION INSTRUCTIONS

Part Number 33-2374

This filter fits: **SEE CATALOG FOR CURRENT APPLICATIONS**

FREE K&N DECAL** To register your warranty, please see us online at knfilters.com/register. **FREE K&N DECAL

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter is a direct replacement for the stock air filter, and no modifications will be required. However, the following procedures **MUST** be followed to ensure the proper fit and seal of the K&N Filter.

INSTALLATION

1. Locate and remove two screws which secure the stock intake tube. Remove stock intake tube. (Fig.1.)
2. Locate and unlatch two clips which are located at the top of the vehicle's air box. Remove the factory air box base, then, remove the stock air filter. (Fig.2)
3. Place the K&N air filter into the base of the airbox. If properly positioned, the two tabs on the K&N air filter will be at rest inside the two tabs in the air box.
4. Verify air filter was placed correctly into the air box. (Fig. 3.)
5. Re-install the air box base and secure by relatching the clips that were unlatched in step two.
6. Re-install the stock intake tube and secure with the two screws that were removed in step one.

**THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED;
OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.**



Fig. 1



Fig. 2



Fig. 3