

**PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE FITTING THIS KIT.**

**If you have a problem, however small, call our Technical Department.**

Tel:- 01925 636950. Fax:- 01925 243111. Mon to Thurs 8.30am - 5pm.

- 1 Release the hose on the intake pipe, the two nuts under the air filter box and the nut at the front of the air box.
- 2 Remove the crankcase breather pipe from the base of the air box.
- 3 Remove the complete air box including the air intake pipe that runs from the slam panel to the base of the air box.
- 4 **See Drawing A instructions.**
- 5 **See Drawing B instructions.**
- 6 **See Drawing C instructions.**
- 7 **Tuning**  
We suggest a **CO** test is carried out, as some cars may be set weaker than the standard setting. The **CO** figure should be no more than **0.5%** above the standard setting.
- 8 **Filter Maintenance.**  
Under normal conditions clean and reoil the filter at approx. 40,000 miles 65,000 km.  
**Use only K&N cleaner and oil** and follow the instructions carefully.

**FITTING YOUR OWN 57i KIT**

If not, **it is essential** that the person fitting the kit (e.g. mechanic) **carefully follows these particular instructions** even if he has fitted K&N kits before. This will save you both time and money. Kits incorrectly fitted may show a loss in performance e.g. the positioning of the essential cold air hose, (flexi expandable and rubber hoses are used).

**A final check** under the bonnet, by yourself, with the instructions, would seem sensible.

**This kit Should Contain :-**

|                              |                                 |                               |
|------------------------------|---------------------------------|-------------------------------|
| 1 x Clamp-on filter.         | 1 x Hose clip size 60.          | 1 x Bracket.                  |
| 1 x Metal tube.              | 1 x Cold air hose assembly.     | 1 x Instruction sheet.        |
| 1 x Instruction pack:-       | 1 x Filter maintenance sheet.   | 1 x K&N window sticker.       |
|                              | 1 x Million mile warranty card. | 1 x Leaflet.                  |
| 1 x Fixing kit containing :- | 1 x Plastic tube.               | 1 x Plastic cable tie (10cm). |
|                              | 1 x Plastic cable ties (19cm).  | 1 x Small bracket.            |
|                              | 1 x M6 nut.                     | 1 x 6mm spring washer.        |

**K&N filters are pre-oiled ready to fit.**


**The advantage's of K&N's cold air intake system.**

Cooler air being denser will show positive improvements in power over systems that draw hot air from the engine bay.


**57-0003-3**

Replace the spring clip.  
Keep clear of filter hose clip.

**Drawing A**



**Drawing B**



**Drawing C**

