

## Part Number 57-0330 INSTALLATION INSTRUCTIONS

Nissan Primera 2.0L 1.6v L4 148bhp 1990 – Nov 1996

1. Unclip & remove the electrical harness plug from the MAS (Mass Air Sensor). (Fig. 1)
2. Unclip & remove the intake hose from the MAS. (Fig. 2)
3. Unclip & remove the air box lid / filter assembly from the air box base & remove the assembly from the vehicle. (Fig 3&4)
4. Remove the 3 bolts from inside the air box base & the bolt securing pick-up pipe to the slam panel. Carefully remove the air box base assembly from the vehicle. (Fig. 5&6)
5. Screw the new studded rubber mounting into original air box mounting threaded hole located on the inner wing. (Fig. 7)
6. Secure the new mounting bracket to the studded rubber mounting using a nylock nut & flat washer supplied. (Fig. 8)
7. Unbolt & carefully remove the MAS from the air box lid. (Fig. 9)
8. Fit the new plastic filter adaptor to the MAS using the bolts, flat washers & nylock nuts supplied. (Fig.10)
9. Refit the MAS assembly to the intake hose & secure using the original hose clip. (Fig.11&12)
10. Fit the new air filter to the MAS / filter adaptor & firmly tighten the #60 hose clamp supplied. Attach the studded lid of the air filter to the mounting bracket using a nylock nut & flat washer supplied. (Fig.13)
11. Reconnect the electrical harness plug to the MAS. (Fig.14)
12. Carefully lengthen the flexi cold air hose supplied & feed the hose down to the lower spoiler. Secure the top of the hose to finish approx.10cm /4" from the air filter using plastic ties supplied. (Secure the hose away from clutch lever & cooling fan). (Fig.15)
13. Taking all necessary safety precautions as per manufacturers instructions raise the front of the vehicle. Ovalise the end of the cold air hose & insert the hose into the air duct located in the lower bumper. Drill / pierce two holes in the air duct & secure the cold air hose using a plastic tie supplied. (Fig.16&17)
14. Carry out a final check of the height / alignment of the K&N induction system before starting the engine. Installation is now complete.

**Parts list:**

- 1 x Air filter Element.
- 1 x Plastic Filter Adaptor.
- 1 x Cold Air Assembly.
- 1 x Literature Pack.

**Fixing Kit :-**

- 1 x Mounting Bracket.
- 6 x Nylock Nut.
- 6 x Flat Metal Washer.
- 3 x Plastic Tie.
- 1 x Studded Rubber Mounting.
- 4 x Allen Head Bolt.
- 1 x #60 Hose Clamp.

**WARNING:** Before starting the engine carry out a final fitment check of the K&N performance kit. It will be necessary for all intake systems to be checked periodically for realignment, clearance and tightening of all connections. Failure to follow the above instructions or proper maintenance may void the warranty.

**FILTER MAINTENANCE:** K&N suggests checking the filter periodically for excessive dirt build-up. When the element becomes covered in dirt (or once a year), service it according to the instructions on the Recharger service kit available from your K&N dealer, part number 99- 5003EU.

For cleaning instructions please visit our website: [www.knfilters.com/cleaning](http://www.knfilters.com/cleaning)



Fig. # 1



Fig. # 2



Fig. # 3



Fig. # 4



Fig. # 5



Fig. # 6



Fig. # 7



Fig. # 8



Fig. # 9



Fig. # 10



Fig. # 11



Fig. # 12

# Part Number 57-0330

Nissan Primera 2.0L 1.6v 4cyl 148bhp Sep 1990 – Nov 1996



Fig. # 13



Fig. # 14



Fig. # 15



Fig. # 16



Fig. # 17

