



57-0338

INSTALLATION INSTRUCTIONS

OPEL FRONTERA B / VAUXHALL FRONTERA 3.2L V6 24v 1998-2004



This Kit Should Contain:

- 1 x Air Filter.
- 1 x Cold Air Hose Assembly.
- 1 x Instruction Sheet.
- 1 x Instruction Pack :-
- 1 x Filter Maintenance Sheet.
- 1 x Leaflet.
- 1 x K&N Window Sticker.
- 1 x Million Mile Warranty.

1 x Fixing Kit :-

- 1 x #60 Hose Clip.
- 1 x M6 Nut.
- 1 x 6 mm Spring Washer.
- 1 x Flat Washer.
- 2 x Long Plastic Ties.
- 1 x Bracket.

Your car and the engine bay should look like the ones in these pictures, if not then talk to your kit supplier.

Should you still have a problem, call K&N customer services. Tel: 01925-636950. Fax: 01925-418948.

FITTING YOUR 57i KIT

When fitting the kit it is **essential** that you **carefully follow these particular instructions**. Kits fitted incorrectly may show a loss in performance, e.g. the positioning of the essential cold air hose, (flexi expandable and rubber hoses are used).

Photo A

1. Unclip and remove the MAS (Mass Air Sensor) from the air box lid.

2. Unclip and remove the air box lid from the air box base.

3. Remove the 3 screws securing the air box base and lift out the assembly.



MAS

Photo B

1. Fit the new mounting bracket to the original rear air box mounting point using the original screw.

2. Fit the new filter onto the MAS. Do not push in beyond the step, as this will affect airflow. Tighten the clip until the filter just turns, Rotate the filter until the K&N logo is straight then tighten the clip one full turn (360 degrees) **no more**, **Do not overtighten the clip.**



3. Attach the studded lid of the filter to the mounting bracket and secure with a nut and washers supplied.

4. Carefully lengthen the flexi cold air hose and feed the hose past the side of the radiator to the front grille. Secure the hose using a long plastic tie. Position the end of the flexi cold air hose to finish **10 cm / 4"** from the filter **no nearer.**

Photo C



Feed the flexi cold air hose to the front grille. Pierce / drill a 3 mm hole in the plastic sleeve on the hose and secure the hose to the grille using a long plastic tie supplied.

Tuning.

CAT. Cars. No adjustments are required.

An increase in fuel may be required if further engine modifications are to be carried out.

Filter maintenance.

Under normal conditions clean and re-oil the filter at approx. 40,000 miles / 65,000 Km.

Use only K&N cleaner and oil and follow the instructions carefully.

K&N filters are pre-oiled ready to fit.

The advantages of K&N's cold air intake system

Cooler air being denser will show positive improvements in power over filter systems that draw hot air from the engine bay.