



INSTALLATION INSTRUCTIONS

Part Number: 66-5090, 66-5100, 66-5110, 66-5120

Billet Aluminum Spoke Lid Assembly

Do not attempt to install this kit until you have read and completely understand these installation instructions. Proper installation requires basic automotive hand tools and a reasonable amount of mechanical knowledge.

INSTALLATION

- 1) Disconnect the vehicle's negative battery cable.
- 2) Remove the stock air cleaner assembly in place.
- 3) Install the gasket, base plate, filter element, and top plate.

NOTE: Care must be taken to ensure the filter is properly seated into the base and top plates.

- 4) Install the supplied countersunk bolt (**cut length to fit**) through top plate.
- 5) Re-connect battery cable. Double check to make sure that everything is tight and properly positioned before starting the vehicle.

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.

FREE K&N DECAL** To register your warranty, please see us online at knfilters.com/register. **FREE K&N DECAL

• 1455 CITRUS AVE., P.O. BOX 1329, RIVERSIDE, CA., U.S.A. 92502 • TECH SERVICE 800-858-3333 • FAX 909-684-9060
• e-mail: tech@knfilters.com • WWW: <http://www.knfilters.com>

18033
11/14/03



INSTALLATION INSTRUCTIONS

Part Number: 66-5090, 66-5100, 66-5110, 66-5120

Billet Aluminum Spoke Lid Assembly

Do not attempt to install this kit until you have read and completely understand these installation instructions. Proper installation requires basic automotive hand tools and a reasonable amount of mechanical knowledge.

INSTALLATION

- 1) Disconnect the vehicle's negative battery cable.
- 2) Remove the stock air cleaner assembly in place.
- 3) Install the gasket, base plate, filter element, and top plate.

NOTE: Care must be taken to ensure the filter is properly seated into the base and top plates.

- 4) Install the supplied countersunk bolt (**cut length to fit**) through top plate.
- 5) Re-connect battery cable. Double check to make sure that everything is tight and properly positioned before starting the vehicle.

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.

FREE K&N DECAL** To register your warranty, please see us online at knfilters.com/register. **FREE K&N DECAL

• 1455 CITRUS AVE., P.O. BOX 1329, RIVERSIDE, CA., U.S.A. 92502 • TECH SERVICE 800-858-3333 • FAX 909-684-9060
• e-mail: tech@knfilters.com • WWW: <http://www.knfilters.com>

18033
11/14/03