



INSTALLATION INSTRUCTIONS

PART NUMBER: BM-8006

This filter fits:

SEE CATALOG FOR CURRENT APPLICATIONS

* **FREE K&N® decal** To register your warranty, please see us online at knfilters.com/register. **FREE K&N® decal** *

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N® air filter seals properly.

INSTALLATION for BMW Models:

1. Remove the stock air filter.
2. Carefully clean the intake snorkel where the air filter sits.
3. Install the K&N® air filter into the intake snorkel. (fig. 1)
4. Reinstall the intake snorkel.
5. Slightly push down on the intake snorkel to make sure it is completely seated.
6. Fasten the stock clips. (fig. 2)

INSTALLATION for Husqvarna Models:

1. Remove the tank cover.
2. Disconnect the temperature sensor plug. (fig. 3)
3. Remove the air filter housing lid. (fig. 4)
4. Remove the paper air filter and install the K&N® filter.
5. Reinstall air filter housing lid, connect temperature sensor, and install tank cover.

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.



fig. 1



fig. 2



fig. 3



fig. 4