



Brake Line Kit Installation

Monroe, WA · 360 453 2030 · www.longacracing.com

Basic Brake Line Installation Tips:

1. Pre-Install kit before painting frame
2. Attach frame tabs after locating hard lines to eliminate or reduce field made double flares
3. Attach Adel® clamps after hard lines are installed
4. Check all connections for leaks. **Field Flares MUST be double flare type**

