



Bolt the Roll-off mounting bolts into the rear of both levelers.  
\*Blue Loctite is recommended\*

