



QUALITY... PLAIN & SIMPLE®

Connector Cable Installation

EC-8000U & EC-8000HT (37-48 Ford)

Connector Cable Installation Instructions

Part# EC-8000U & EC-8000HT (37-48 Ford)
For Under-the-Dash Hand Operated Emergency Brake

Building American Quality... With A Lifetime Warranty!

10924 Murdock Dr. • Knoxville, TN 37932

TOLL FREE 1-877-469-7440 • (865) 966-2269 • FAX (865) 671-1999 • tech@lokar.com • www.lokar.com

Connector Cable Installation

Step 1: Install outer housing to hand brake with E-Clip as shown in **Fig. 1**.

Step 2: Run housing back to rear cables. If you are using a Lokar Universal Rear Emergency Brake Cable Kit, mount connector cable bracket 9 1/2" from rear cable adjuster as shown in **Fig. 2**.

Step 3: Run inner cable from hand brake, using clevis end at hand brake. Make sure hand brake is in the full off position.

Step 4: Be sure to adjust the adjusters all the way in when connecting cables as shown in **Fig. 2**.

Step 5: Adjust all cables as needed to remove any slack.

Fig. 1



Fig. 2

