

FULL SWEEP BOOST/VAC WITH BACK MAP SENSOR HARNESS WIRE IDENTIFICATION AND POSITION (viewed from the wire IN side of the plug)



WEB-1001

WIRING DIAGRAM

