



1969-72 NOVA wo AC ACCESSORY KIT PACKING LIST

ACCESSORY KIT
784176

No.	QTY.	PART No.	DESCRIPTION	
1.	3	06200-VUE	2" DUCT HOSE	
2.	10	06250-VUE	2 1/2" DUCT HOSE	
3.	1	62566-VCE	PLASTIC FRESH AIR CAP	
4.	1	629969	BEZEL 68-72 NOVA wo AC CENTER/PS LOUVER	
5.	1	494052	1961-72 CHEVY DS LOUVER BEZEL	
6.	1	49069-VCI	GLOVE BOX	
7.	1	636676-VCA	67-72 CAMARO/NOVA DEFROST KIT	
8.	2	49056-VUL	3 1/2" x 1 1/2" IN DASH LOUVER	
9.	2	49057-VUL	LOUVER w/ 2 1/2" HA 4 3/4" x 1 1/2"	
10.	1	648229	69-72 CAMARO/NOVA wo AC FIREWALL COVER ASM	
11.	1	232600-VUA	GEN IV UNIVERSAL WIRING KIT	
12.	1	643169-FCA	67-72 CAMARO/NOVA w/wo AC BRKT KIT	
13.	1	633173	69-72 NOVA wo AC INSTALLATION KIT	
14.	1	474171	69-72 NOVA wo AC CONTROL PANEL CONV. KIT	
15.	1	626667	66-72 CHEVELLE/NOVA KICK PANEL FRESH AIR CAP	

CHECKED BY: _____
PACKED BY: _____
DATE: _____

