



Packing List: Accessory Kit (781180) 1969 Pontiac Firebird with A/C

No.	Qty.	Part No.	Description
1.	4	06200-VUE	2" Duct Hose
2.	11	06250-VUE	2 1/2" Duct Hose
3.	1	62566-VCE	Plastic Fresh Air Cap
4.	1	49068-VCI	Glove Box Top
5.	1	49067-VCI	Glove Box Bottom
6.	1	498850-VCA	1969 Camaro/Firebird Pass. Side Fresh Air Cover Assembly
7.	1	498840-VCA	1969 Camaro/Firebird Driver Side Fresh Air Cover Assembly
8.	1	636676-VCA	1967-72 Chevy/Firebird Defrost Kit
9.	1	648228	Cover, 1967-81 Chevy/Firebird with A/C Firewall Assembly
10.	1	232600-VUA	Gen IV Universal Wiring Kit
11.	1	643178	Bracket Kit 1969 Firebird Evaporator
12.	1	633155	Installation Kit 1969 Firebird with A/C
13.	1	625056	1967-81 Chevy/Firebird Kick Panel Fresh Air Cap
14.	1	626681	69 Firebird with A/C Center Louver Hose Adapter
15.	1	474165	69 Firebird with A/C Panel Conversion Kit
16.	2	49870-VCI	Driver/Passenger Side OEM Louver Hose Adapter

Checked By: _____
Packed By: _____
Date: _____

