



350 S. St. Charles St. Jasper, In. 47546
Ph. 812.482.2932 Fax 812.634.6632
www.ridetech.com

Part # 11280709
65-70 Impala Master Series NA Rear Shock Kit

Components:

2	24079999	7" stroke Non Adjustable shock
2	90002021	1.7" NA eyelet
4	90001694	.625" bearing
8	90001995	Snap ring for bearing
2	90002010	Extended T-bar – Installed in shock body
4	90001980	Snap ring for T-bar
4	90002042	Aluminum bearing spacer - .625" I.D.
2	90001619	Round head cantilever pin
2	90000471	Aluminum spacer
4	90002067	Aluminum spacer for bearing

Hardware:

4	99371004	3/8" x 1 1/4" USS bolt	Shock to frame
8	99373003	3/8" SAE flat washer	Shock to frame
4	99372002	3/8" USS Nylok nut	Shock to frame

350 S. St. Charles St. Jasper, In. 47546
Ph. 812.482.2932 Fax 812.634.6632
www.ridetech.com

Installation Instructions



1. Fasten the upper shock T-bar to the bottom of the frame using two 5/16" x 1" bolts, Nylok nuts and flat washers.

2. Use the new cantilever pin supplied to attach the bottom of the shock to the axle.



1. Cantilever Pin
2. Aluminum Bearing Spacer
3. .625" Bearing
4. Aluminum Spacer
5. Factory axle bracket
6. 1/2" Lock Washer
7. 1/2" SAE Nut

