



350 S. St. Charles St. Jasper, In. 47546
Ph. 812.482.2932 Fax 812.634.6632
www.ridetech.com

Part # 11380501
99-06 Silverado Front HQ Series Shock Kit
For Use with CoolRide

Shock:

2	22849999	HQ Smooth Body Shock Cartridge
2	70011138	3/4" ID Shock Bushing
2	90002103	5/8" ID Inner Sleeve

Components:

4	70011140	Stem Bushings
4	70011141	Stem Washers
1	90000378	Drivers side upper shock mount
1	90000379	Passenger side upper shock mount
2	90000471	Aluminum shock spacer
2	90001619	Shock stud

Hardware:

2	99373007	3/8" x 1" self tapping bolt	Shock mount to frame
8	99373003	3/8 SAE flat washer	Shock mount to frame
4	99372002	3/8" USS Nylok nut	Shock mount to frame
4	99371003	3/8" x 1" USS bolt	Shock mount to frame
2	99372005	3/8"- 24 Nyloc Nut	Upper Shock Stud

Installation Instructions



1. The upper shock mount will bolt the rear upper control arm mounting bracket and to the side of the frame rail. It will use one existing hole in the control arm bracket. A 2nd 3/8" hole must be drilled in the control arm bracket. A 5/16" hole must be drilled into the frame rail for the 3/8" self tapping bolts.

2. Fasten the shock to the bracket using new bushings/hardware supplied.

3. The lower shock stud must be welded to the rear leg of the lower control arm. To determine it's location; place a jack under the lower control arm and fully compress the air spring. Then fully compress the shock absorber. Swing the shock up to the center of the control arm and mark the center of the eye. Drill 5/8" hole in the arm and then weld in the stud.

4. Fasten the shock to the stud w/ hardware supplied.

