



**INSTALLATION INSTRUCTIONS:**

1. Install the new switch into your dash using the original bezel and nut. It will be necessary to cut the shaft for a nice custom installation. **Please take note of the flat area cut onto the threaded brass mounting shaft of the switch, and the square edge cut into switch mounting area on the face of the dash. These two features are to help the switch index properly in the face of the dash.**
2. Install the shaft in switch being certain that it is fully engaged inside the switch. Once the shaft is fully seated down inside the switch in the "off" position, place the knob on end of shaft. Measure how far away from the dash the bottom face of the knob (closest to dash) is. Allow for 1/4" or so extra so that the knob will not bottom out on dash once the shaft has been cut to length.
3. Remove the shaft from the switch. To do this, pull the shaft completely out to the "on" position. Reach up under the dash and depress the button on RH side of the switch as it is mounted into the dash, and pull the shaft out of the switch. Cut the shaft based on your measurements. It may be necessary to file the end of the shaft once it has been cut in order to reinstall the knob onto the shaft.
4. Attach the knob to the cut shaft and tighten the allen screw.
5. Reinstall your newly customized shaft into your headlight switch assembly.



**American  
Autowire**

www.americanautowire.com 856-933-0801

PART #

**510583**

DESCRIPTION:

Headlight Switch  
1976-86 Jeep CJ Applications  
Classic Update Series

92970966 instruction sheet rev 0.0 10/25/2014