

330 SMITH ST, P.O. BOX 70, ARTHUR ON, N0G 1A0 1-800-865-7366, FX 519-848-3234, info@pros-pick.com

"WOW" STRIPS

KIT CONTENTS

WOW STRIPS come in a set of seven unless otherwise requested The hardware kit should contain 49 "T" bolts

INSTALLATION

When the strips are formed they are cut to length by a guillotine, this pinches the end slightly.

In most applications I prefer to have a pinched end at the tailgate end of the strips. Using a hack saw, cut the pinched end off of one of the strips, lay the cut strip and an uncut strip in the bed to see which end looks better for your application.

Measure the required length carefully. Apply masking tape to the area to be cut, mark the tape at the cut point using a square.

Carefully cut the strip with a hack saw. **USING AN ABRASIVE CUT OFF SAW WILL DISCOLOR THE STRIPS**. Using a small file, remove any burrs caused by cutting the strips.

Slide a sufficient number of T bolts into the strip with the widest side of the clip engaged in the strip. Usually seven are required.

Starting from the front of the bed engage the T bolts into the front cross member, one between the front and second cross member and so on. When all the strips are in place install a small washer, lock washer and nut on each T bolt that goes through a cross member. Stainless steel on stainless has a tendency to gall, a drop of oil on each nut will stop this. The T bolts that are between cross members will require a large flat washer. Go ahead and tighten all the T bolts down. UNDER NO CIRCUMSTANCES USE IMPACT TOOLS TO INSTALL OR REMOVE.

Some makes and models require bed side angles. On these models we recess the carriage bolts to flush with the wood and then fasten the side angles on with two-sided tape.

If you purchased side angles you will have received a piece of tape for each angle, cut each piece into four equal pieces and space them along the side angle. Be sure to clean the surfaces with alcohol before applying tape.

Thank you for purchasing our product. We hope it makes you smile every time you look at them. PRO'S PICK 1-800-865-7366