


Instr. No. 2650-1038

**INSTALLATION**

1. Disconnect negative battery cable.
2. Remove the dash cover.
  - a. Using flat screwdriver or putty knife pry the front edge of the dash cover upward to release front clips.
  - b. Pull dash cover toward you to disengage the panel from the rear clips along the windshield.
3. With the dash cover removed position the Dash Pod, with metal bracket installed, between the two defrost vents on the driver side of the panel.
4. Mark mounting bracket hole locations on the dash cover and drill two  $\frac{3}{16}$ " holes for the screws. Remove metal bracket from dash pod.
5. Create a small,  $\frac{1}{2}$ " -  $\frac{9}{16}$ " opening in the dash cover, approximately 3 inches behind bracket, for gauge wiring to pass through.
6. Fasten metal bracket to dash cover with 2 supplied Allen screws.
7. Install gauges
  - a. Run wires through dash pod and dash cover.
  - b. Do not attach dash pod yet.
8. Replace dash cover.
9. Attach dash pod to bracket with 2 supplied Allen screws.
10. Reconnect negative battery cable.

**Auto Meter Gauge Works Three Year Limited Warranty**

Gauge Works warrants to the consumer that all Auto Meter Gauge Works products will be free from defects in material and workmanship. Products that fail will be repaired or replaced at Auto Meter Gauge Works' option to the consumer, when determined by Auto Meter Gauge Works that the product failed due to defects in material or workmanship. This warranty is limited to the repair or replacement of parts in the Auto Meter Gauge Works Product and the necessary labor done by Auto Meter Gauge Works to effect the repair or replacement of the Auto Meter Gauge Works product. In no event shall this warranty exceed the original purchase price of the Auto Meter Gauge Works product nor shall Auto Meter Gauge Works be responsible for special, incidental or consequential damages or costs incurred due to the failure of this product. Warranty claims to Auto Meter Gauge Works must be transportation prepaid and accompanied with proof of purchase. This warranty applies only to the original purchaser of product and is non-transferable. Improper use or installation, accident, water damage, abuse, unauthorized repairs or alterations voids this warranty. Auto Meter Gauge Works disclaims any liability for consequential damages due to breach of any written or implied warranty on all products manufactured by Auto Meter Gauge Works. This warranty is made solely by Gauge Works with Auto Meter being the agent to contact for warranty claims. If the partnership between Auto Meter and Gauge Works dissolves, then all warranty adjustments will be covered by the Gauge Works Co.

FOR SERVICE CONTACT: AUTO METER PRODUCTS Inc. 413 W. Elm St., Sycamore, IL 60178 USA (815)895-8141 or  
Email us at [service@autometer.com](mailto:service@autometer.com)