

INSTALLATION INSTRUCTIONS

REPLACEMENT CAMARO PILLAR

2650-1539-00

1. DISCONNECT THE BATTERY BEFORE STARTING ANY WORK. Not only are we doing electrical, but you're right next to the side airbag.



2. To start, pull the factory A pillar down. It pops out, but don't try to pull it all the way down.



3. There is a safety strap that needs to be removed to pull the pillar away. The screwdriver is pressing into the point where it is released in this picture.



4. Original A-Pillar removed.



5. The safety strap is then removed from the factory pillar. The tab on the back is depressed and it slides right out.



6. It's then re-installed into the new pillar the exact same way.

7. Install and wire gauges according to the wiring instructions included with each gauge.



8. The safety strap is then reattached to the bracket behind our pillar to secure the new mount.



9. The completed installation.

SERVICE

For service send your product to Auto Meter in a well packed shipping carton. Please include a note explaining what the problem is along with your phone number. If you are sending product back for Warranty adjustment, you must include a copy (or original) of your sales receipt from the place of purchase.

Auto Meter Gauge Works Three Year Limited Warranty

Gauge Works warrants to the consumer that all Auto Meter Gauge Works products will be free from defects in material and workmanship. Products that fail will be repaired or replaced at Auto Meter Gauge Works' option to the consumer, when determined by Auto Meter Gauge Works that the product failed due to defects in material or workmanship. This warranty is limited to the repair or replacement of parts in the Auto Meter Gauge Works Product and the necessary labor done by Auto Meter Gauge Works to effect the repair or replacement of the Auto Meter Gauge Works product. In no event shall this warranty exceed the original purchase price of the Auto Meter Gauge Works product nor shall Auto Meter Gauge Works be responsible for special, incidental or consequential damages or costs incurred due to the failure of this product. Warranty claims to Auto Meter Gauge Works must be transportation prepaid and accompanied with proof of purchase. This warranty applies only to the original purchaser of product and is non-transferable. Improper use or installation, accident, water damage, abuse, unauthorized repairs or alterations voids this warranty. Auto Meter Gauge Works disclaims any liability for consequential damages due to breach of any written or implied warranty on all products manufactured by Auto Meter Gauge Works. This warranty is made solely by Gauge Works with Auto Meter being the agent to contact for warranty claims. If the partnership between Auto Meter and Gauge Works dissolves, then all warranty adjustments will be covered by the Gauge Works Co.