

2005-Present Ford Mustang On-Car Adjustable Panhard Bar
Item # 1044



1. Jack up rear of vehicle to a good working height, make sure both rear wheels are off the ground. Place (2) jack stands under the frame. **Do not Support by rear axle.**
2. Using wrench/socket remove both panhard bar bolts and remove panhard bar from vehicle.
3. Place the new adjustable panhard bar on top of the OEM bar removed. Set the adjustable panhard bar to the approximate length of the OEM panhard bar. To adjust length, loosen both jam nuts, use a 1" wrench and turn adjuster clock wise or counter clock wise. This will shorten or lengthen the bar.
5. Use the supplied grease to lube the polyurethane bushing surfaces of the new panhard bar before install, this will help ease panhard bar into place. Install the panhard bar into place with the adjuster towards the driver's side.
6. Use the OEM hardware from step 2 to secure the panhard bar in place. Do not tighten bolts yet; the vehicle's weight must on the rear axle before tightening to prevent bushing preload and inconsistent vehicle height.
7. Jack up vehicle by rear axle, remove jack stands from frame and place the stands under the rear axle. Release the jack and let the vehicle weight rest on the jack stands.
8. Tighten panhard bar mounting bolts and lube grease fitting with 1-1 ½ pumps of grease only.
9. Adjusting your Panhard Bar- With the panhard bar installed you can now adjust the rear end for proper centering. To determine if adjustment is needed, with the vehicle on the ground measure the distance from each rear wheel to fender well, this will determine which way the axle needs to be moved. For example, by shortening the panhard bar you are moving the axle to the passenger side; by lengthening it you are moving it towards the driver's side. If panhard bar needs adjusted loosen each jam nut and turn adjuster to proper length. Once rear end has been centered tighten each jam nut.

Greasing Your Control Arms- Use marine type grease, marine type grease can not be washed away with water. Grease your control arm bushings 2-3 times a year adding only 1 pump of grease, **DO NOT OVER GREASE.**

Thank you for putting your trust in a UMI Performance product!



509 Hemlock St
Philipsburg, PA 16866
Ph- 814.343.6315 Fax- 814.343.6318

Installation Instructions

support@umiperformance.com
www.umiperformance.com

DISCLAIMER OF WARRANTY

THE PURCHASER ACCEPTS ALL RESPONSIBILITY FOR THE FINAL USE OF THE PRODUCTS PURCHASED AND SHALL HOLD UMI PERFORMANCE INCORPORATED AND ITS REPRESENTATIVES HARMLESS IN ANY LEGAL PROCEEDING ARISING FROM THE USE OF SUCH PRODUCTS.

UMI PERFORMANCE INCORPORATED DOES NOT WARRANT, GUARANTEE, OR MAKE ANY REPRESENTATION REGARDING THE USE, OR THE RESULT OF THE USE OF ANY PERFORMANCE PRODUCT MANUFACTURED OR DISTRIBUTED BY UMI PERFORMANCE INCORPORATED. PURCHASER ASSUMES THE ENTIRE RISK AS THE RESULT AND PERFORMANCE OBTAINED FROM THE INSTALLATION AND USE OF SAID PERFORMANCE PRODUCTS. UMI PERFORMANCE INCORPORATED ASSUMES NO RESPONSIBILITY FOR AND HEREBY DISCLAIMS ALL WARRANTIES, ORAL OR WRITTEN, EXPRESS OR IMPLIED INCLUDING WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY AND OF FITNESS FOR A PARTICULAR PURPOSE.

ALL PARTS ARE WARRANTED TO BE FREE OF DEFECT AT THE TIME OF PURCHASE. WARRANTY IS ONLY EXTENDED TO REPLACEMENT OF PARTS FROM UMI PERFORMANCE INCORPORATED AND DOES NOT COVER LABOR, TOWING OR ANY OTHER DIRECT OR INDIRECT COST. UMI PERFORMANCE INCORPORATED IS NOT RESPONSIBLE FOR ANY CONSEQUENTIAL DAMAGE, EXPENSE OR INJURY ARISING FROM THE USE, MISUSE OR IMPROPER INSTALLATION OF ANY PRODUCT MANUFACTURED AND/OR SOLD BY UMI PERFORMANCE INCORPORATED.

Item # 1044

2005-Present Mustang On-Car Adj. Panhard Bar

UMI Performance Inc.
Made in Pennsylvania, USA

Thank you for putting your trust in a UMI Performance product!

Page 2 of 2

©UMI Performance, Inc.

www.umiperformance.com