



**Hooker 1964-72 GM A-Body 4L60-4L70 Transmission Spacer
12657HKR
Installation Instructions**



Thank you for choosing to use this Hooker™ component as part of your performance project. This bracket is compatible for use with the Hooker **71222007HKR or 71222008HKR** A-body transmission crossmembers only. Please read these instructions in their entirety before attempting installation.

PRE-INSTALLATION CONSIDERATIONS:

This spacer is designed to provide the user of a Hooker **71222007HKR or 71222008HKR** transmission crossmember with the means to install a GM 4L60-4L70 automatic transmission behind an LS engine in any 1964-72 A-body vehicle. Attachment bolts to connect the transmission mount to the crossmember are not included and are to be user sourced.

CAUTION! WORK ONLY ON A LEVEL SURFACE. USE JACKS /JACK STANDS OF SUFFICIENT CAPACITY TO LIFT AND SUPPORT YOUR VEHICLE. NEVER WORK UNDER A VEHICLE SUPPORTED BY A FLOOR OR BUMPER JACK.

INSTALLATION:

NOTE: These instructions have been written with the assumption that your transmission and Hooker transmission crossmember has been installed into the vehicle.

1. Check that the hardware package includes the following:

- (1) Machined aluminum spacer

If any are missing, please contact Technical Service at 1-866-464-6553 or 270-781-9741.

2. Raise the rear of your transmission and install this spacer block between the lower cantilevered shelf of the crossmember and transmission isolator mount.

3. Attach the transmission mount, spacer, and crossmember together with user-supplied hardware of your choice (Grade 8 recommended).