



INSTALLATION INSTRUCTIONS

Part Number: BA-2201

This filter fits: See catalog for current applications

* **FREE K&N® decal** To register your warranty, please see us online at knfilters.com/register. **FREE K&N® decal** *

Congratulations, you have just purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N® air filter seals properly.

INSTALLATION:

1. Remove the stock air filter.
2. Using the provided K&N® sealing grease, place a bead of grease around the perimeter of the air filter. (Fig. 1)
3. With the greased side of the filter facing the rear of the airbox, slide the air filter into the airbox opening, applying pressure to the outer edges of the air filter. When the air filter is completely in, the outer edge will sit flush with the air filter inlet. (Fig. 2)
4. With your finger, wipe grease across the top of where the K&N® air filter and airbox meet, remove any excess grease. (Fig. 3 & 4)
5. Reinstall the airbox lid and fasten with the 4 OE screws.

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.



Fig. 1



Fig. 2



Fig. 3



Fig. 4