

MSD INSTALLATION INSTRUCTIONS

Inductive Sync Pickup PN 7555

ONLINE PRODUCT REGISTRATION: Register your MSD product online. Registering your product will help if there is ever a warranty issue with your product and helps the MSD R&D team create new products that you ask for! Go to www.msperformance.com/registration.

Parts Included:


- 1 – Inductive Sync Pickup
- 1 – 8-foot Fiber Optic Cable with Sleeve
- 1 – Tie Wrap

The Inductive Sync Pickup provides an easy and reliable way to obtain a synchronization signal for MSD's Digital Programmable Ignitions and Accessories. The pickup simply slides over the number one spark plug wire and senses each firing of the spark plug. The fiber optic cable connects to the MSD Control while providing a clean signal that will not interfere with other electronics. No phasing or alignment is required with this pickup.

Note: It is not recommended to cut the fiber optic cable. If the cable is too long, it is preferred to loop the cable and secure it.

1. Route the number one spark plug wire through the pickup. It is best to position the pickup, close the distributor. Secure the pickup with the supplied wire tie.
2. Insert the fiber optic cable into the Pickup. Snug the cinch nut – do not overtighten!
3. Route the cable to the Ignition Control. Use care to keep the cable away from engine heat sources, edges and moving parts. Snug the cinch nut – do not overtighten!

If your fiber optic cable is ever damaged, MSD offers a replacement as PN 7556.



TECH NOTES

Service

In case of malfunction, this MSD component will be repaired free of charge according to the terms of the warranty. When returning MSD components for warranty service, **Proof of Purchase** must be supplied for verification. After the warranty period has expired, repair service is based on a minimum and maximum fee.

All returns must have a Return Material Authorization (RMA) number issued to them before being returned. To obtain an RMA number please contact MSD Customer Service at 1 (888) MSD-7859 or visit our website at www.msdpower.com/rma to automatically obtain a number and shipping information.

When returning the unit for repair, leave all wires at the length in which you have them installed. Be sure to include a detailed account of any problems experienced, and what components and accessories are installed on the vehicle. The repaired unit will be returned as soon as possible using Ground shipping methods (ground shipping is covered by warranty). For more information, call MSD at (915) 855-7123. MSD technicians are available from 7:00 a.m. to 5:00 p.m. Monday - Friday (mountain time).

Limited Warranty

MSD warrants this product to be free from defects in material and workmanship under its intended normal use*, when properly installed and purchased from an authorized MSD dealer, for a period of one year from the date of the original purchase. This warranty is void for any products purchased through auction websites. If found to be defective as mentioned above, it will be repaired or replaced at the option of MSD. Any item that is covered under this warranty will be returned free of charge using Ground shipping methods.

This shall constitute the sole remedy of the purchaser and the sole liability of MSD. To the extent permitted by law, the foregoing is exclusive and in lieu of all other warranties or representation whether expressed or implied, including any implied warranty of merchantability or fitness. In no event shall MSD or its suppliers be liable for special or consequential damages.

*Intended normal use means that this item is being used as was originally intended and for the original application as sold by MSD. Any modifications to this item or if it is used on an application other than what MSD markets the product, the warranty will be void. It is the sole responsibility of the customer to determine that this item will work for the application they are intending. MSD will accept no liability for custom applications.