



**IDLE KICK-UP SOLENOID W/ BRACKET
KIT P/N 1950**

1. Mount the bracket on the manifold stud as shown.
2. Insert the solenoid through the bracket and tighten the jam nut.
3. Install a minimum 16 gauge (switched 12V) wire to power solenoid.
4. With the key ON, rotate the hex head clockwise or counter-clockwise to set the idle speed.

LIT712
Date: 2-27-12

Technical Support: 1-270-901-3346



**IDLE KICK-UP SOLENOID W/ BRACKET
KIT P/N 1950**

1. Mount the bracket on the manifold stud as shown.
2. Insert the solenoid through the bracket and tighten the jam nut.
3. Install a minimum 16 gauge (switched 12V) wire to power solenoid.
4. With the key ON, rotate the hex head clockwise or counter-clockwise to set the idle speed.

LIT712
Date: 2-27-12

Technical Support: 1-270-901-3346



**IDLE KICK-UP SOLENOID W/ BRACKET
KIT P/N 1950**

1. Mount the bracket on the manifold stud as shown.
2. Insert the solenoid through the bracket and tighten the jam nut.
3. Install a minimum 16 gauge (switched 12V) wire to power solenoid.
4. With the key ON, rotate the hex head clockwise or counter-clockwise to set the idle speed.

LIT712
Date: 2-27-12

Technical Support: 1-270-901-3346



**IDLE KICK-UP SOLENOID W/ BRACKET
KIT P/N 1950**

1. Mount the bracket on the manifold stud as shown.
2. Insert the solenoid through the bracket and tighten the jam nut.
3. Install a minimum 16 gauge (switched 12V) wire to power solenoid.
4. With the key ON, rotate the hex head clockwise or counter-clockwise to set the idle speed.

LIT712
Date: 2-27-12

Technical Support: 1-270-901-3346

