



Front Axle Tether System Installation Instructions



*Cinch to Motor
Mount Tube*

Right Front Pictured

*Mount Axle Clamp
to OUTSIDE of Radius
Rod Mount Bracket*

IMPORTANT:

- Axle Clamp **MUST** be Installed OUTSIDE of Radius Rod Mount Brackets
- Rope Follows Lower Radius Rods from Motor Mount Vertical Tubes to Axle Clamps
- Custom Length Tethers Available for Cars With Non-Standard Radius Rod Lengths
- Titanium Hardware Kits Available

Front Axle Tether System Installation Instructions

BUTLERBUILT®
Professional Seat Systems™

