



Installation Instructions HURST NITRO STICK 2 - WIRING DIAGRAM

Fits: All Hurst Manual Shifters

HURST # 5381001


WORK SAFELY! For maximum safety, perform this installation on a clean, level surface and with the engine turned off. Place blocks or wedges in front of and behind both rear wheels to prevent movement in either direction.

CAUTION: To avoid any possibility of bodily injury or damage to vehicle, do not attempt installation until you are confident that the vehicle is safely secured and will not move.

ILLUMINATING SWITCH: can be used for multiple applications i.e. Nitrous, Line-Lock, Roll Control, etc.

IMPORTANT! Disconnect negative terminal from the battery before any electrical work.

INSPECT! After wiring the switch to the device, make sure wires are properly insulated to prevent short(s).



IMPORTANT: RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE

Technical Service

A highly trained technical service department is maintained by Hurst Performance to answer your technical questions, provide additional product information and offer various recommendations.

Technical service calls, correspondence, and warranty questions should be directed to:



Hurst Performance Products

(707) 544-4761

www.Hurst-Shifters.com